

Simplicity
4040

OWNER'S MANUAL
AGRICULTURAL
AND
INDUSTRIAL
TRACTOR

SER. FORM - 027
LITHO IN U.S.A.

REVISED 2/1/72

SIMPLICITY MANUFACTURING COMPANY, INC.

1341

TO THE OWNER

Congratulations on your purchase of the Simplicity 4040 tractor. It has been designed with emphasis on the ability to do your most important jobs quickly and efficiently with the least operator effort. The versatile hydrostatic transmission allows you to shift from forward to reverse without stopping to change gears. With it you can also select exactly the right ground speed for any condition without changing engine speed and decreasing attachment efficiency. Simplicity has provided you with a large selection of quality engineered attachments specifically designed for the 4040 to make it truly a tractor for all seasons. We have shown some in this manual — many others are available from your Simplicity dealer.

So that you can get the very most from your purchase, you and anyone else who may operate the tractor should study this manual and the owners manual for your attachments before using the 4040 tractor. It will help us add you to our long list of satisfied Simplicity customers. Throughout the manual, we will refer to directions as left, right, front and rear. These directions are as the operator sits on the tractor seat, with the clutch pedal on the left side of the tractor, the brake pedals on the right, the engine toward the front, and the tractor draw bar at the rear.

For your own safety, and that of your family and friends, periodically review the safety tips. You will find the table of contents and alphabetized index very useful in referring to this manual when questions arise in the future. We have provided you with information to perform most service jobs quickly and easily, but your Simplicity dealer will be happy to help you with any service or repair work.

When ordering replacement parts for your 4040 tractor, be prepared to give your Simplicity dealer the identification numbers found on the tractor and engine identification plates shown below. The identification plate for the tractor is found on the right side of the frame below the tractor seat. The one for the engine is located on the left side of the engine blower housing (side opposite the engine oil filter). Locate the numbers and record them below for easy reference.

SIMPLICITY MANUFACTURING CO., INC.	
PORT WASHINGTON, WIS., U. S. A.	
Refer to I.d. no. when	
writing or ordering parts.	
I. D. No.	<input type="text"/>

TRACTOR IDENTIFICATION PLATE

Onan ®	
MODEL AND SPEC NO. <input type="text"/>	
SERIAL NO.	<input type="text"/>
IMPORTANT - ALWAYS GIVE ABOVE NOS. WHEN ORDERING PARTS	
CHECK OIL LEVEL DAILY	
CHANGE OIL EVERY 50 HOURS	
OIL CAPACITY	<input type="text" value="3.5"/> QTS
BELOW 30 F----5W30	
ABOVE 30 F---- 30	
FOR EXTREME OPERATING	
TEMPERATURES, SEE YOUR	
SERVICE MANUAL	
BATTERY---	<input type="text" value="12"/> VOLT
MANUFACTURED BY	
ONAN	
DIVISION OF ONAN CORPORATION	
MINNEAPOLIS, MINNESOTA, U.S.A.	
99A1216	

ENGINE IDENTIFICATION PLATE

PERIODICALLY REVIEW THE SAFETY PRECAUTIONS FOUND IN THE SAFETY SECTION OF THIS MANUAL

TABLE OF CONTENTS

SIMPLICITY NEW EQUIPMENT WARRANTY	1	SEAT ADJUSTMENT	19
PROTECT YOURSELF AND OTHERS	2	WHEEL TREAD ADJUSTMENT	19
SIMPLICITY OFFERS YOU	3	WEIGHTING WITH CALCIUM CHLORIDE	22
OPERATION	4	MAINTENANCE	23
INSTRUMENTS AND CONTROLS	4	ORDERING REPLACEMENT PARTS	23
BEFORE OPERATING THE TRACTOR	8	EVERY 5 HOURS	23
STARTING THE ENGINE	8	EVERY 25 HOURS	23
STOPPING THE ENGINE	8	SCHEDULED MAINTENANCE CHART	24
BREAK-IN PROCEDURE	9	EVERY 50 HOURS	25
CONTROLLING TRACTOR GROUND SPEED	9	EVERY 100 HOURS	26
HOT WEATHER OPERATION	9	EVERY 200 HOURS	27
OPERATION CHART	10	EVERY 400 HOURS	29
COLD WEATHER OPERATION	12	ACCESSORIES	32
DUSTY OPERATING CONDITIONS	12	REAR WHEEL WEIGHTS	32
OUT OF SERVICE PROTECTION (STORAGE)	12	TIRE CHAINS	32
STARTING THE TRACTOR AFTER STORAGE	12	HYDRAULIC CYLINDER	32
TROUBLE SHOOTING GUIDE	13	FRONT BUMPER	33
ADJUSTMENTS	15	ATTACHMENTS	34
CARBURETOR	15	FRONT MOUNTED ATTACHMENTS	34
GOVERNOR ADJUSTMENT	15	CENTER MOUNTED ATTACHMENTS	34
TRACTION CLUTCH BELT TENSION	16	REAR MOUNTED ATTACHMENTS	34
CLUTCH PEDAL FREE TRAVEL	16	THREE POINT HITCH	34
HYDROSTATIC TRANSMISSION NEUTRAL	17	ATTACHING POWER TAKE OFF	36
NEUTRAL SAFETY STARTING SWITCH	18	SPECIFICATIONS	37
BRAKE ADJUSTMENT	18	INDEX	41

SIMPLICITY NEW EQUIPMENT WARRANTY

The Company warrants Simplicity products to be free from defects in material and workmanship, except the Company makes no warranty, express or implied, with respect to tires, engines, generators and voltage regulators, which are warranted by their respective manufacturers. Any part covered by this warranty which is proven defective within one year (6 months for equipment used for rental, municipal or commercial purposes) under normal use, from date of purchase, will be replaced without charge, provided such part is returned to the factory, (if requested), and is found to be defective upon examination at the factory. This warranty does not apply to any Simplicity products altered outside of the Simplicity factory. **THE FOREGOING WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, PERFORMANCE, OR OTHERWISE.** The Company's obligation under its warranty is strictly and exclusively limited to the replacement of such parts, and in no event shall the Company be liable for any other damages, whether direct, immediate, incidental, special, or consequential. Simplicity Manufacturing Company, Inc., reserves the right to modify or change specifications without prior notification. There are no warranties which extend beyond the description of any Simplicity product.

SAFETY PRECAUTIONS TO PROTECT YOURSELF AND OTHERS

OPERATION

Know the controls and how to stop quickly - **READ THE OWNER'S MANUAL.**

Do not allow children to operate vehicle. Do not allow adults to operate it without proper instruction.

Do not carry passengers. **KEEP CHILDREN AND PETS A SAFE DISTANCE AWAY.**

Clear work area of objects which might be picked up and thrown.

Take all possible precautions when leaving vehicle unattended; such as disengaging power-take-off, lowering attachments, shifting into neutral, setting parking brake, stopping engine and removing key.

Do not stop or start suddenly when going uphill or downhill. Mow up and down the face of steep slopes; never across the face.

Reduce speed on slopes and in sharp turns to prevent tipping or loss of control. Exercise extreme caution when changing direction on slopes.

Stay alert for holes in terrain and other hidden hazards.

Use care when pulling loads or using heavy equipment.

- A. Use only approved drawbar hitch points.
- B. Limit loads to those you can safely control.
- C. Do not turn sharply. Use care when backing.
- D. Use counterweight (s) or wheel weights when suggested in owner's manual.

Watch out for traffic when crossing or near roadways.

Keep all nuts, bolts, and screws tight to be sure equipment is in safe working condition.

Do not alter basic engine governor settings or overspeed engine.

Do not operate equipment when barefoot or wearing open sandals. Always wear substantial footwear.

FUEL & FIRE HAZARDS

Handle gasoline with care -- it is highly flammable.

- A. Use approved gasoline container.
- B. Never remove cap or add gasoline to a running or hot engine or fill fuel tank indoors. Wipe up spilled gasoline.

- C. Open doors if engine is run in garage -- exhaust fumes are dangerous. Do not run engine indoors.

Never store equipment with gasoline in the tank inside a building where fumes may reach an open flame or spark.

Allow engine to cool before storing in any enclosure.

To reduce fire hazard keep engine free of grass, leaves or excessive grease.

ATTACHMENTS

Disengage all attachment clutches and shift into neutral before attempting to start engine.

Disengage power to attachments and stop engine before leaving operator position.

Disengage power to attachment (s) and stop engine before making any repairs or adjustments.

Disengage power to attachments when transporting or not in use.

When using any attachments never direct discharge of material toward bystanders or allow anyone near vehicle while in operation.

Keep vehicle and attachments in good operating condition and keep safety devices in place. Use guards as instructed in owner's manual.

Vehicle and attachments should be stopped and inspected for damage after striking a foreign object and the damage should be repaired before restarting and operating the equipment.

When using vehicle with mower:

- (1) Mow only in daylight or in good artificial light.
- (2) Never make a cutting height adjustment while engine is running if operator must dismount to do so.
- (3) Shut engine off when unclogging chute.
- (4) Check blade mounting bolts for proper tightness at frequent intervals.

Stop blades when crossing gravel drives, walks or roads.

If the equipment should start to vibrate abnormally, stop the engine and check immediately for the cause. Vibration is generally a warning of trouble.

SIMPLICITY OFFERS YOU

The Simplicity 4040. It's a new concept, a new size in tractors... designed from the ground up to do its jobs better and faster than any tractor before it. Integrated design matches tractor, attachments, and function for optimum performance. Not an overgrown garden tractor, not a stripped-down ag or industrial model, the 4040 is specifically engineered to fill the gap that has existed between these categories. It's designed to deliver high performance on a host of rugged jobs... small-acreage farming and utility chores, industrial and institutional groundskeeping, club maintenance, suburban estate care and similar work.

You'll find feature after feature on the Simplicity 4040 that other tractors simply don't offer. Features that tailor it ideally to the jobs it's meant to do. Like the unique combination of hydrostatic drive and 3-speed transmission, that permits selection of precisely the right combination of power and speed for any job, while attachments run at peak efficiency. This drive system also affords effortless, convenient clutchless ground speed changing and reversing.

The 4040 also offers power takeoffs that operate independently of the tractor transmission. Driven directly off the engine through electromagnetic clutches, the PTOs deliver continuous power to attachments, so work gets done quickly and efficiently.

The rugged, fast-acting hydraulic lift system on the 4040 also helps speed up work and reduce effort. It lets the operator position either front-center or rear-mounted attachments quickly, precisely, with just the touch of a finger.

Hydrostatic drive and 3-speed transmission. Only the 4040 offers this combination. Hydrostatic drive gives an infinite selection of speeds -- to 10.4 mph forward, 6.2 mph in reverse -- controlled by one simple lever, with no need to de-clutch even when changing direction. Three-speed gearbox lets you select the efficient power range for any job. Limited-slip differential... reduces wheel-spin under slippery conditions.

Reliable 16-1/2 H. P. Onan Engine. It's demonstrated amazing dependability in hundreds of thousands of hours. Air-cooled, to end radiator problems. No oil mixing, thanks to 4-cycle design. Full-pressure lubrication with oil filter. Stellite valves with rotators. Modern shortstroke over-square design.

Hydraulics. Fast, precise, powerful action for lifting attachments and positioning them with no operator effort. Driven by hydrostatic system's charge pump. Standard for center or rear-mounted attachments, optional for front.

Power - Takeoffs. Driven directly from engine, independent of tractor transmission and ground speed. Full engine power is always available to attachments. Front PTO is standard, rear is optional. Electromagnetic PTO clutches operated by convenient toggle switches on instrument panel.


High ground clearance. The 4040 is a full 15" above the ground, to clear row crops easily and work better in snow or soft soil. Even with removable drawbar in place, clearance is still 13".

Big disc brakes. Plenty of stopping power from two independent disc brakes on rear wheels. Can be operated independently to aid in steering or controlling slippage, or simultaneously for safe, sure stops.

Operators convenience. Comfortable, convenient, easy to get on or off. Controls all located within easy reach. Instrument panel is easy to read. Seat adjusts to suit any operator. Footrests and pedals are non-skid for safety.

3-point hitch (optional). A must for farm work, or any job requiring rear-mounted implements. Designed for Category "O" tools. Adjusting screws control attachment tilt.

Tires. Choose the type that fits the job. Agricultural tires are standard, with offset wheels that can be reversed to vary tread according to crop spacing. Optional tires offered include turf type, or high-flotation, or heavy-duty front tires for use with end loader.



TURF TIRES SHOWN ARE OPTIONAL

Simplicity
POWER-EQUIPMENT

OPERATION




Figure 1. Tractor instrument panel as seen from the operators position on tractor seat.

INSTRUMENTS AND CONTROLS-HOW TO UNDERSTAND AND USE THEM

Picture yourself seated on your Simplicity 4040 tractor. Before starting the engine, let's learn how to understand and use the instruments and controls. The paragraphs referring to the instruments and controls are illustrated on figures 1 through 4.

IGNITION SWITCH: (Figure 1, item E) To actuate the ignition switch first insert the ignition key as shown. When the key is turned clockwise to the first position, the ignition is ON. In the ON position the lights, hourmeter, etc. will operate. Turn the key clockwise past the ON position to the START position to actuate the starter. **THE HYDROSTATIC TRANSMISSION CONTROL LEVER MUST BE IN THE NEUTRAL POSITION AND THE FRONT AND REAR (OPTIONAL) ELECTRIC CLUTCH SWITCHES IN THE "OFF" POSITION BEFORE THE STARTER WILL ACTUATE.** Release the key as soon as the engine starts. Return the key to the vertical position to stop the engine. **CAUTION: ALWAYS REMOVE THE IGNITION KEY WHEN CLEANING, ADJUSTING OR SERVICING THE TRACTOR OR ANY ATTACHMENT OR WHEN LEAVING THE VEHICLE UNATTENDED.**

CHOKE CONTROL KNOB: (Figure 1, item J) The choke control knob may be pulled out to increase the amount of fuel entering the engine for starting and cold weather warmup. When starting a cold engine in cold weather pull the choke knob all the way out. Little or no choke is normally required to start the engine when the air temperature is above 70°F or while the engine is still warm from being recently run. After the engine has started, push the choke in slowly. In cold weather, it may be necessary to leave the choke pulled out slightly for 3 or 4 minutes while the engine warms up. **NEVER OPERATE THE ENGINE WITH THE CHOKE OUT AFTER IT HAS HAD SUFFICIENT TIME TO WARM UP - ABOUT 5 MINUTES SHOULD BE SUFFICIENT EVEN IN COLD WEATHER.**

ENGINE SPEED CONTROL LEVER: (Figure 1, item K) The engine speed control lever is used to set the desired engine speed. The speed control lever should be moved forward away from the operator to increase engine speed and back toward the operator to reduce engine speed. Consult the appropriate section of this manual for specific information on suggested settings of the engine speed control lever. For example: Starting the engine - page 8, Controlling Tractor Ground Speed - page 9 and the Chart on page 10.

OIL PRESSURE WARNING LIGHT: (Figure 1, item C) The oil pressure warning light marked **OIL** will glow red when the oil pressure to the moving parts of the engine is low. You can insure the light is functioning properly each time you use the tractor by noting that the light will come on when the ignition switch is turned to the **ON** position. If the red **OIL** light comes on when the engine is running, **STOP THE ENGINE IMMEDIATELY.** Check the oil level in the engine crankcase to insure it is full. Also insure that you are using the proper grade and weight of oil for the weather conditions. See page 23 of this manual for instructions on checking the oil level and selecting the proper grade and weight of oil. After insuring the crankcase is filled with the correct oil, start the engine. If the oil light does not go out after the engine has run for 10 seconds, stop the engine immediately and call your Simplicity dealer. **NEVER OPERATE THE ENGINE WHEN THE OIL PRESSURE WARNING LIGHT IS LIT.**

TRANSMISSION OIL (FLUID) TEMPERATURE WARNING LIGHT: (Figure 1, item B) The transmission oil temperature warning light marked **HOT** will glow red when the transmission oil reaches an unsafe temperature. **IF THE LIGHT COMES ON — STOP THE TRACTOR IMMEDIATELY.** The **HOT** light may have come on because the transmission oil cooler, located behind the engine, is dirty or you are operating with the transmission in too high a gear. See page 23 of this manual for instructions on cleaning the oil cooler. After insuring the oil cooler is clean, allow the oil to cool until the light goes out before operating the tractor. The oil will cool fastest if the hydrostatic transmission control lever is placed in the neutral position and the tractor engine run at full speed. If the oil cooler was quite dirty you may be able to proceed with your work in the same gear as before after the **HOT** light has gone out. If, however, the cooler was relatively clean when the light went on, you should shift to the next lower gear before continuing. The chart on page 10 of this manual will give you a good idea of which gear should be used for most operations.

AMMETER: (Figure 1, item M) The ammeter indicates the number of amperes of electricity being added to or drawn from the battery. The dial indicator will move right to the (+) Charging position when electrical energy is being added to the battery and left to the (–) Discharge position when electrical energy is being drawn from the battery. The indicator will normally fluctuate around the dial center or to the (+) side of the dial. It is normal for the indicator to show some discharge when the engine is idling; however, it should move to the center or to the charge position as the engine speed is increased. If the ammeter remains in the discharge position with the engine at full speed, the alternator or regulator may not be functioning properly. Check the 30 ampere fuse located at the right front corner of the engine (item E on figure 28). See your Simplicity dealer if replacing the fuse does not correct the problem.

FRONT CLUTCH: (Figure 1, item F) The front power take off switch is used to actuate the electrically controlled power take off clutch which drives center or front mounted attachments such as the center mounted rotary mower, sickle bar, or front mounted snow thrower. To actuate the clutch, move the switch forward to the **ON** position. Pull the switch back to the **OFF** position to stop the attachment.

THE POWER TAKE OFF CONTROL SWITCH MUST BE IN THE "OFF" POSITION IN ORDER FOR THE ENGINE STARTER TO OPERATE.

REAR CLUTCH: (OPTIONAL - FACTORY INSTALLED ONLY) (Figure 1, item G) The rear power take off switch is used to actuate the electric clutch which controls the power take off drive to rear mounted attachments such as the rotary tiller. To operate the rear power take off, move the switch forward to the **ON** position. To stop the power take off, pull the switch back to the **"OFF"** position. **BOTH THE FRONT AND REAR POWER TAKE OFF CONTROL SWITCHES MUST BE IN THE "OFF" POSITION IN ORDER FOR THE ENGINE STARTER TO OPERATE.**

LIGHT SWITCH: (Figure 1, item I) The light switch should be pushed forward to the **ON** position to turn on the tractor lights. To prevent the lights from being turned on by unauthorized persons, the ignition switch must also be in the **ON** position for the lights to operate. To turn the lights off, pull the light switch back to the **OFF** position.

HOURLMETER: (OPTIONAL - FACTORY OR FIELD INSTALLED) (Figure 1, item H) The hourmeter records the number of hours the engine runs; however, since it is electrically operated it will run anytime the ignition switch is in the **ON** position even though the engine may not be running. The hourmeter is useful in keeping accurate maintenance records and also a convenient way of telling how much time the tractor has been used on a particular job.

FUEL GAUGE AND FILLER CAP: (Figure 1, item N) The fuel gauge indicates the amount of fuel in the tank. Before adding fuel, shut off the engine and allow it to cool. To remove the fuel gauge and filler cap for adding gasoline, turn the fuel filler gauge-cap counter-clockwise. The fuel tank holds approximately 3.8 gallons - enough for about 4 hours of mowing or 3 hours of plowing. **CAUTION: DO NOT ALLOW LIGHTED CIGARETTES, MATCHES, ETC., AROUND ANY OPEN GASOLINE CONTAINER. DO NOT OVER FILL; WIPE UP ANY SPILLED GASOLINE.**

AUXILIARY CONTROL SWITCH: (OPTIONAL - FIELD INSTALLED) (Figure 1, item D) The auxiliary control switch is used when an electrical control device is required in the operation of an attachment. An example is the electric motor used to rotate the discharge spout of the snow thrower attachment. When this switch is installed refer to the owners manual of the attachment you are using for a complete explanation of how the switch is to be used.

HYDRAULIC LIFT CONTROL LEVER: (Figure 1, item A) The hydraulic control lever controls the flow of oil used to operate the hydraulic cylinder. The hydraulic cylinder is normally connected to the lift cables which raise center mounted attachments. If the tractor is equipped with the 3-point hitch (optional - factory or field installed), the hydraulic control lever can also control rear attachments mounted on the 3-point hitch such as a rotary tiller or a moldboard plow. See page 34 for complete information on using the 3-point hitch. The hydraulic cylinder can also be used to control front mounted attachments such as the

snow thrower or dozer blade if the front hydraulic kit (optional - factory or field installed) is installed. If you have the front hydraulic kit or have purchased an additional cylinder as an accessory, see page 32 of the Accessories section of this manual for specific instructions on how to hook up the cylinder hoses and how to use the cylinder. When the control lever is in the center **HOLD** position, the hydraulic cylinder and any attachment connected to it will hold in its position. Move the hydraulic control lever rearward to raise an attachment. When the attachment has been raised to the desired height, release the control lever and it will return to the **HOLD** position. To lower or put down-pressure on an attachment, move the hydraulic control lever forward to the **LOWER** position and hold it there until the attachment has reached the desired position. When using attachments such as the snow thrower or rotary tiller, it is often desirable to operate the hydraulic system in the **FLOAT** position. The **FLOAT** position allows the hydraulic cylinder to extend or retract as the attachment moves up and down following the contour of the ground surface. The hydraulic control lever may be placed in the **FLOAT** position by pushing it forward past the **LOWER** position. When the hydraulic control lever has been placed in the **FLOAT** position, it will remain there until it is pulled rearward. For specific information on controlling a particular attachment with the hydraulic system, see the owners manual for that attachment.

HYDROSTATIC TRANSMISSION CONTROL LEVER:

(Figure 1, item L) The hydrostatic transmission control lever regulates the direction and amount of oil (fluid) pumped by the hydrostatic transmission pump to drive the tractor and is used to control both the direction of travel and the ground speed of the tractor. **NEUTRAL** position for the hydrostatic transmission control lever is as shown with the back of the control lever guide resting against the notched portion of the guide. The hydrostatic transmission control lever must be in this neutral position for the engine starter to operate. To move the tractor **FORWARD**, grip the control lever squeezing the lock release lever toward the knob and move the control lever forward. The 3-speed transmission must also be in gear for the tractor to drive. See page 6 for instructions on how to shift the 3 speed transmission. The farther forward from neutral the control lever is pushed, the faster the tractor will move forward at a given engine speed. To slow or stop the tractor when it is moving forward, squeeze the lock release lever toward the knob and pull the control lever rearward slowly toward the neutral position. You can place the hydrostatic transmission in neutral from the forward position without watching it by slightly pushing to the right on the control lever as it is moved rearward. The control lever will stop against the notched portion of the guide when it reaches neutral. To move the tractor in **REVERSE**, squeeze the trigger of the hydrostatic control lever toward the knob, push the lever to the left and pull it back from the neutral position. The farther back the control lever is moved, the faster the tractor will travel in reverse. To stop the tractor while moving in reverse, squeeze the trigger toward the knob and move it forward slowly to the neutral position. In emergency situations, you may use the clutch and brakes to stop. **CAUTION: THE CLUTCH MUST BE DISENGAGED FOR THE BRAKES TO STOP THE TRACTOR EFFECTIVELY.**

CLUTCH PEDAL: (Figure 2, item A) The clutch pedal





Figure 2. Clutch and parking brake lock on left side of tractor.

is used to disconnect the tractor transmission from the engine. To disengage the clutch, press down on the clutch pedal. Release the clutch slowly to engage it. The clutch is very useful when starting a cold engine, since when the clutch is disengaged the starter motor is not required to turn the transmission, so will leave more battery power for starting the engine. When the engine is running, the clutch pedal should be used for emergency stops only. Since the tractor is equipped with a hydrostatic transmission, the clutch is not required for starting, stopping, or shifting gears. It is not advisable to use the clutch for inching or starting forward movement of the tractor. The tractor can be inched and started more smoothly by using the hydrostatic control lever. See page 6 for more specific information on using the hydrostatic control lever.

THREE SPEED TRANSMISSION SHIFT LEVER:

(Figure 3, item A) The three speed transmission shift lever is used to select neutral or first, second or third speed range in the gear transmission. The transmission is in **NEUTRAL** when the transmission shift lever is free to slide forward and rearward about 1-1/2 inches. To place the transmission in **FIRST** gear, pull the shift lever forward all the way and then push down. The transmission is in **SECOND** gear when the shift lever is pulled all the way forward and then pulled up. **THIRD** gear is located by pushing the transmission shift lever all the way to the rear and then pushing down. To shift the transmission into or out of any gear, place the hydrostatic transmission control lever in the neutral position (Figure 1, item N). It is not necessary and not advised to disengage the clutch. The clutch pedal should be released (clutch pedal out) to aid in meshing the gears. When shifting from neutral into gear, it may be necessary to move the hydrostatic control lever forward from the neutral position slightly (about 1/4 inch) to rotate the gears in the transmission so they mesh. As a safety precaution it is advisable




GEAR	FORWARD	REVERSE
1	0 - 4.2 MPH	0 - 2.6 MPH
2	0 - 6.3 MPH	0 - 4.0 MPH
3	0 - 10.4 MPH	0 - 6.2 MPH

SEAT ADJUSTING LEVER: (Optional - factory or field installed) (Figure 3, item B) The seat adjusting lever is used to adjust the front to rear position of the optional spring mounted seat. The seat position can be adjusted while sitting on it by moving the seat adjustment lever to the left and sliding the seat forward or back as desired. The seat can be locked in several positions over the four inch adjustment range. To lock the seat in position, simply release the adjustment lever. For instructions on adjusting the position of the standard seat, see page 19 in the Adjustments section of this manual.

BRAKES: (Figure 4, item A) **CAUTION: THE CLUTCH PEDAL MUST BE DEPRESSED TO GET EFFECTIVE BRAKING ACTION.** The 4040 tractor is equipped with individual disk type rear wheel brakes. They should be applied simultaneously except when required as an aid in turning. This can be done by placing your foot half on each brake and applying pressure to both at the same time, but it is much better to lock the two brakes together by moving the sliding pin (B) located in the left brake pedal to the right through

the hole in the right brake pedal. The tractor should normally be operated with the brakes locked together. With the pin in place, the two brake pedals will move together to give faster and safer stopping. The brakes should also be locked together when the parking brake lock is used. See page 7 for more information on the parking brake lock. When the brakes are not locked together, pushing down on the right brake pedal will brake the right rear wheel and pushing down on the left brake pedal will brake the left rear wheel. Used individually, the brakes will decrease the turning radius of the tractor. To make a sharp turn to the right, turn the steering wheel all the way to the right and apply the right wheel brake. Turn the steering wheel to the left and use the left wheel brake to make a sharp turn to the left. **DO NOT APPLY THE BRAKES INDIVIDUALLY WHEN THE TRACTOR IS MOVING OVER 6 MILES PER HOUR AS THE OPERATOR MAY LOSE CONTROL OF THE TRACTOR.**

PARKING BRAKE LOCK: (Figure 2, item B) The parking brake lock control located on the left side of the tractor should be used to lock the brakes in position after the tractor has been brought to a stop and before the operator leaves the tractor seat. When using the parking brake, the right and left brake pedals should be locked together, (see Brakes). If the brake pedals are not locked together, only the left brake will hold when the parking brake is set. To set the parking brake, apply pressure to the brake pedals with your right foot. At the same time, push the parking brake lock down as far as possible. Release the brake pedals. After pressure has been taken off the brake pedals, the parking brake lock will stay in position. To release the parking brake, apply pressure to the brake pedals and pull the parking brake lock up to the **OFF** position. Since the parking brake lock holds the left brake pedal directly the parking brake will hold better and release easier if pressure is applied to the left brake pedal when setting and releasing it.



BEFORE OPERATING THE TRACTOR

Though your Simplicity dealer may have performed the before starting checks listed below, we suggest you personally check each one so that you will become familiar with them and also to insure that your tractor is ready to operate the first time you use it.

TIRE INFLATION: Tires should be checked and inflated as required prior to operating. Inflate the tires according to the chart on page 23 in the Maintenance section of this manual.

CRANKCASE OIL: Before starting the engine, insure the engine crankcase is filled with the correct grade and weight of oil. See page 23 in the Maintenance section of this manual for instructions on checking the oil and the correct oil to use.

FUEL SUPPLY: Fill the fuel tank completely with clean fresh **REGULAR** grade automotive gasoline. **DO NOT MIX OIL WITH GASOLINE.** Premium grade gasolines are not recommended as they increase carbon deposits in the engine. **CAUTION: GASOLINE IS HIGHLY FLAMMABLE. NEVER ALLOW ARTICLES SUCH AS LIGHTED MATCHES OR CIGARETTES WHICH COULD CAUSE IT TO IGNITE NEAR OPEN GASOLINE CONTAINERS. DO NOT OVERFILL - WIPE UP ANY SPILLED FUEL. BE SURE THE ENGINE IS NOT RUNNING WHEN ADDING FUEL.**

TRANSMISSION: The transmission oil (fluid) level should be checked and the transmission filled with type A, type F, or Dexron automotive transmission oil to the check cock (Figure 23 item A).

AIR CLEANER: Insure that the air cleaner element is in place and properly sealed. If it is dirty, clean or replace it according to the instructions on page 25 in the Maintenance section of this manual.

BATTERY: Check the battery to be sure it is filled to the proper level with electrolyte and the vent holes in each of the filler caps are open. See page 23 in the Maintenance instructions.

DROP HOUSINGS: The two drop housings located on either side of the transmission should be filled to the check plug with 90 weight transmission oil. See page 27 in the Maintenance section for the location of the check and filler plugs.

LUBRICATION: Lubricate all grease fittings shown in figures 26, 37, and 53 of this manual. Use general purpose automotive grease. A pisto-luber grease gun specially designed for this purpose is available from your Simplicity dealer.

ATTACHMENTS: Read and become familiar with the Attachments Manual for any attachments you are using with your tractor.

SEAT ADJUSTMENT: The seat should be adjusted so the operator can comfortably depress the clutch and brake pedals while sitting back in the seat. See page 7 in the In-

struments and Controls section for instructions on adjusting the optional spring mounted seat or page 19 in the Adjustments section if your tractor is equipped with the standard seat.

BRAKE PEDAL PIN: Use the sliding pin in the brake pedals to lock the brakes together unless the tractor is to be used for agricultural work and the brakes are required for turning.

STARTING THE ENGINE

1. Refer to the Instruments and Controls section beginning on page 4 of this manual for the location and use of the instruments and controls. **CAUTION: IT IS DANGEROUS TO START THE TRACTOR UNLESS YOU ARE SEATED IN THE TRACTOR SEAT.** Insure that the power take off clutch switches are in the **OFF** position and the hydrostatic transmission control lever is in the **NEUTRAL** position.
2. As a safety precaution, it is also advisable to place the 3-speed transmission lever in **NEUTRAL** to insure the tractor does not move forward or backward unexpectedly when the engine starts.
3. Move the engine speed control lever forward midway between slow and fast.
4. Pull the choke knob out. In cold weather, pull it all the way out. In warmer weather or when starting an engine which is still warm from recent operation less choke will be required.
5. Depress the clutch pedal and hold it down to disengage the transmission drive. Although the engine may be started without disengaging the clutch, in cold weather it will start easier with the clutch disengaged since the starting motor will not have to turn the transmission in addition to the engine.
6. Insert the ignition key and turn it to the right past the **ON** position to the **START** position to engage the starter motor. As you turn the key, check the **HOT** and **OIL** warning lights to see that they are functioning properly. The **OIL** light should light up when the key is turned to the **ON** position and the **HOT** light when the engine starting motor engages.
7. When the engine starts, release the key and allow it to return to the **ON** position. Slowly push the choke in. After the engine has run for a few minutes it should not require any choking. If the engine does not start after about 10 seconds of cranking it may be receiving too rich a fuel mixture. Push the choke in and try again. The engine may not need to be choked when starting it in warm weather or if it has been operated recently.
8. Release the clutch pedal as soon as the engine is running smoothly.

STOPPING THE ENGINE

1. Move the engine speed control lever to the **SLOW** position.
2. If the tractor has been operating under full load, allow the engine to idle for about a minute to reduce the engine temperature. Stopping a hot engine too suddenly can damage engine parts.
3. Turn the ignition key counter-clockwise to the vertical position to stop the engine.
4. Set the parking brake.
5. Remove the ignition key to prevent unauthorized use of the tractor.

BREAK-IN PROCEDURE

Controlled break-in with proper oil and a conscientiously applied maintenance program will help assure satisfactory service for many hours from the Onan engine used in your Simplicity 4040.

Break-in or ideal fitting of all internal moving metal parts can best be achieved by maintaining proper cooling and correct lubrication during the running-in period. The tractor should be run at about half load for the first three hours with intermittent periods of full load to control engine break in. Engine parts damage can be caused by using the wrong grade and weight of oil and high engine operating temperatures during break-in.

Check the oil level at least every 5 operating hours. Add oil to keep it between the **LOW** and **FULL** marks on the dipstick, but never overfill as overfilling may cause the oil to foam and enter the breather system.

Drain the initial oil fill after 25 hours of operation while the engine is hot. After the initial oil change, change the oil every 50 operating hours.

CONTROLLING TRACTOR GROUND SPEED

Tractor ground speed can be controlled by the transmission gear selected, the position of the hydrostatic transmission control lever, and by adjusting the engine speed control.

ENGINE SPEED

Most power take off driven attachments operate best at a particular speed. Since the speed of the power take off drive is directly related to the engine speed, it is not desirable to adjust the engine speed to control the ground speed of the tractor when power take off driven attachments are being used. For pulling light loads or transporting the tractor and attachments from one area to another, adjusting the engine speed is one method of controlling tractor ground speed.

SELECTING TRANSMISSION GEAR

The best method of controlling the tractor ground speed is by setting the engine speed according to the engine load or the speed required for the attachment and then use the transmission controls to select the desired ground speed.

Select a gear in the three speed transmission which will give you the desired speed range. See the chart on page 10 for proper gear selection.

For light loads and conditions where you may wish to vary the ground speed frequently, such as when mowing, second or third gear range would normally be best.

When pulling heavy drawbar loads such as a moldboard plow, the tractor will operate more efficiently if first or second gear range is used. If the red **HOT** light on the dash should light up, shift to a lower gear. See the paragraph on Trans-

mission Oil Temperature Warning Light on page 5 .

HYDROSTATIC TRANSMISSION CONTROL

After selecting the transmission gear, use the hydrostatic control lever to give the exact ground speed you desire. The chart (page 10) is given as a guide to use for setting the controls for performing various operations. A range or choice is given for most jobs since varying operating conditions require different settings.

STARTING TRACTOR TRAVEL: Assure yourself that the area you are going to drive the tractor in is free of obstructions. After you have selected the desired transmission gear, release the parking brake and look around to insure there are no obstructions in your path. To start the tractor in motion, squeeze the trigger of the hydrostatic control lever with your right hand and move it forward or back from the **NEUTRAL** position slowly until you have reached the desired speed. **DO NOT USE THE CLUTCH TO BEGIN MOTION AS IT IS DESIGNED FOR USE WHEN STARTING THE ENGINE AND EMERGENCY STOPS ONLY.** Always move the hydrostatic control lever slowly to prevent abrupt and dangerous speed changes. **CAUTION: DO NOT STOP OR START SUDDENLY WHEN GOING UPHILL OR DOWNHILL. MOW UP AND DOWN THE FACE OF STEEP SLOPES; NEVER ACROSS THE FACE. REDUCE SPEED ON SLOPES AND IN SHARP TURNS TO PREVENT TIPPING OR LOSS OF CONTROL. EXERCISE EXTREME CAUTION WHEN CHANGING DIRECTION ON SLOPES.**

STOPPING TRACTOR TRAVEL: To stop the tractor squeeze the trigger toward the hydrostatic transmission control lever and move the lever slowly toward the **NEUTRAL** position. In emergencies or if both hands are required on the steering wheel, you may depress the clutch and brake pedals to stop the tractor. Before leaving the tractor seat, shut off the engine, set the parking brake, and remove the ignition key.

HOT WEATHER OPERATION

When operating the tractor in temperatures above 75°F pay particular attention to the following items to prevent damage.

1. Keep the engine cooling fins clean and free of obstruction which would decrease air flow to and from the engine. See page 29 for cleaning instructions.
2. Keep the transmission oil (fluid) cooler clean and free of dirt and chaff which would restrict air flow. Also keep the cooler free of oil. An oil film on the outside of the cooler greatly reduces its cooling ability. See page 23 for instructions on cleaning the fluid cooler.
3. Insure that you are using the proper grade and weight of oil in the engine for the temperature the tractor is being used in. Check the oil level each time you fill the fuel tank.
4. Check the battery water level more frequently than every 25 hours which is recommended under normal conditions. High temperatures cause faster evaporation.

Attachment	Engine Speed Control	Transmission Gear Selection	Hydrostatic Lever Position	Approx. Ground Speed (MPH)	Required Accessories and Options	Recommended Accessories and Options
Transporting Tractor		1 — ② 3	N — F R	3 - 6		
		1 — 2 ③	N — F R	5 - 10		
60" Center Mounted Rotary Mower (Smooth terrain - normal grass)		1 — ② 3	N — F R	4 - 6	Hitch assembly for mid-mounted attachments	Front turf tires and wheels Rear turf or high flotation tires and wheels
		1 — 2 ③	N — F R	6 - 8		
60" Center Mounted Rotary Mower (Rough terrain - heavy or wet grass)		① — 2 3	N — F R	2 - 3	Hitch assembly for mid-mounted attachments.	Front turf tires and wheels Rear turf or high flotation tires and wheels Rear wheel weights
		1 — ② 3	N — F R	3 - 4		
58" Sickle Bar		1 — ② 3	N — F R	2 - 4	Hitch assembly for mid-mounted attachments.	Rear wheel weights for side hill mowing
		1 — 2 ③	N — F R	4 - 6		
48" Rear Mounted Mower		1 — ② 3	N — F R	3 - 4	Rear Power take off Three point hitch	Front weight Front bumper
		1 — ② ③	N — F R	4 - 6		
52" Snow Thrower (Light snow)		1 — ② 3	N — F R	3 - 4	Hitch assembly for front mounted attachments Front hydraulic kit.	Tire chains Rear wheel weights Front and rear agricultural tires and wheels
		1 — 2 ③	N — F R	4 - 5		
52" Snow Thrower (Heavy or wet snow)		① — 2 3	N — F R	1 - 2	Hitch assembly for front mounted attachments Front hydraulic kit	Tire chains Rear wheel weights Front and rear agricultural tires and wheels
		1 — ② 3	N — F R	3 - 4		





































Attachment	Engine Speed Control	Transmission Gear Selection	Hydrostatic Lever Position	Approx. Ground Speed (MPH)	Required Accessories and Options	Recommended Accessories and Options
60" Snow Plow and Dozer Blade				2 - 3	Hitch assembly for front mounted attachments. Front hydraulic kit	Tire chains Rear wheel weights
				3 - 5		
Rear Mounted Grader Blade				2 - 3	Three point hitch	Tire chains Rear wheel weights Front weight Front bumper
				3 - 5		
48" Rotary Tiller				1	Three point hitch Rear power take off	Front weight Front bumper
				1 - 2		
12" Mounted Plow				1 - 2	Three point hitch	Front agricultural tires and wheels Rear agricultural tires and wheels Front weight Rear wheel weights (2 sets) Front bumper
				2 - 3		
Cultivator or Planter				2 - 3	Three point hitch	Front agricultural tires and wheels Rear agricultural tires and wheels Rear wheel weights
				3 - 5		
Front End Loader				1 - 3	Front high capacity tires and wheels	Tire chains Rear wheel weights
				3 - 5		
REFER TO YOUR ATTACHMENT OWNERS MANUALS FOR ADDITIONAL INFORMATION.						

Figure 5. Operation Chart

COLD WEATHER OPERATION

When the tractor is being used in temperatures below 30°F, check the following items closely:

1. Use the correct grade and weight of oil for the temperature conditions. Change the oil only when the engine is warm. If an unexpected temperature drop occurs when the engine is filled with summer oil, before starting the engine, move the tractor to a warm location until the oil will flow freely.
2. Use fresh fuel. Fill the fuel tank after each days use to protect against moisture condensation.
3. Disengage the clutch when starting the engine.
4. If you have added calcium chloride solution to the tires to give added traction, insure that the calcium chloride to water ratio is high enough to prevent the solution from freezing. See the chart on page 22.

DUSTY OPERATING CONDITIONS

When the tractor is operated in dusty or dirty conditions check the following items closely:

1. Keep the engine and transmission oil cooler fins clean and free of materials which will decrease air flow.
2. Service the air cleaner more frequently. Clean and replace it as often as necessary to allow air to flow to the carburetor freely. Cleaning may be required as often as every 10 hours under extremely dusty operating conditions. Also, check the air louvers on top of the tractor hood to see that they are fully open.
3. Change the engine oil and oil filter more frequently. The oil should be changed more often than every 50 hours as is recommended under normal conditions. Change the oil filter every other time the oil is changed.
4. Check the engine governor linkage more often than every 200 hours as is recommended under normal operating conditions.

OUT OF SERVICE PROTECTION (STORAGE)

When the tractor is to be stored without use for three months

or longer, the following precautions should be taken to insure your tractor will be ready to go when you need it:

1. Unless you wish to run the tractor until the fuel tank is empty, add a good brand of gasoline stabilizer. This additive, Stabil, available from your Simplicity dealer, prevents formation of gum and varnish for up to one year, providing easier starting and a cleaner fuel system.
2. Drain and refill the engine crankcase while the engine is warm. Tie a tag on the tractor indicating what grade and weight of oil was used.
3. Remove the spark plugs and pour one ounce (two tablespoons) of SAE 50 oil (SAE 30 oil if SAE 50 is not available) into each cylinder. Engage the starter to turn the engine over a few times and reinstall the spark plugs.
4. Clean the air cleaner element.
5. Clean the governor linkage.
6. Plug the exhaust outlet to prevent the entrance of moisture, dirt, bugs, etc.
7. Insure the battery is filled to the proper level with water and is fully charged. Battery life will be increased if it is removed and put in a cool, dry place and fully charged about once a month.
8. Grease all grease zerks and put oil on the lubrication points shown in the Maintenance section.
9. If the tractor is to be stored 6 months or longer block the tractor up off the wheels to relieve weight and keep the tires off a damp floor. Protect the tires from prolonged exposure to direct sunlight.
10. Store the tractor in a dry place indoors.

STARTING THE TRACTOR AFTER STORAGE

Before starting the tractor after it has been stored, do the following:

1. Remove the blocks from under the tractor.
2. Replace the battery.
3. Unplug the exhaust outlet.
4. Perform the "Before Operating the Tractor" instructions found on page 8 of this manual.

TROUBLE SHOOTING GUIDE

PROBLEM OR SYMPTOM	POSSIBLE CAUSES	CHECKS AND CORRECTIONS
Starter will not turn engine over.	<p>Hydrostatic control lever not in neutral position.</p> <p>Front or rear clutch switch not in OFF position.</p> <p>Battery discharged or dead.</p> <p>Protective fuse blown.</p> <p>Neutral safety start switch not properly adjusted</p> <p>Wiring loose or broken.</p>	<p>Move hydrostatic control lever to neutral.</p> <p>Move switches to OFF position.</p> <p>Check the battery - charge or replace as necessary.</p> <p>Replace 30 Ampere fuse. See figure 28, item E .</p> <p>Adjust the safety switch. See page 18.</p> <p>Visually check wiring, replace any broken or frayed wires, tighten loose connections.</p>
Engine turns — will not start.	<p>Out of fuel.</p> <p>Engine flooded.</p> <p>Crankcase oil too heavy.</p> <p>Fuel filter plugged.</p> <p>Water in gasoline.</p> <p>Breaker points or spark plugs worn or dirty.</p> <p>Engine timing incorrect.</p>	<p>Fill fuel tank.</p> <p>Push choke in, attempt to start.</p> <p>Change oil as recommended on page 25.</p> <p>Replace fuel filter. See page 27.</p> <p>Remove fuel tank and clean, replace fuel filter.</p> <p>Check and replace or set. See page 27 and 28.</p> <p>Set timing. See page 28.</p>
Engine starts hard or runs poorly.	<p>Fuel mixture too rich.</p> <p>Fuel mixture too lean.</p> <p>Breaker points or spark plugs worn or dirty.</p> <p>Engine timing incorrect.</p>	<p>Push choke in. Clean air filter element. See page 25. Set idle needle. See page 15.</p> <p>Set idle needle. See page 15.</p> <p>Check and replace or set. See page 27 and 28.</p> <p>Set timing. See page 28.</p>
Engine knocks.	<p>Not enough oil in crankcase.</p> <p>Using wrong weight of oil.</p> <p>Using wrong grade of gasoline.</p> <p>Timing incorrect.</p>	<p>Add oil as required. See page 23.</p> <p>Change oil, use weight recommended for weather conditions. See page 25.</p> <p>Use regular grade automotive gasoline.</p> <p>Set timing. See page 28.</p>
Electric clutch won't engage.	<p>Wire loose or unplugged.</p> <p>Circuit breaker open.</p>	<p>Check wires and see if the wires are plugged together.</p> <p>Allow circuit breaker to cool.</p>
Tractor drive clutch will not disengage.	<p>Too much clutch free travel.</p> <p>Belt stop not properly adjusted.</p>	<p>Adjust clutch pedal free travel. See page 16.</p> <p>Adjust belt stop. See page 16, step 6.</p>

TROUBLE SHOOTING GUIDE

PROBLEM OR SYMPTOM	POSSIBLE CAUSES	CHECKS AND CORRECTIONS
Engine speed too high or too low	Incorrect governor setting Governor linkage dirty or binding.	Adjust governor. See page 15. Clean and inspect governor linkage. See page 28.
Engine will not idle smoothly	Air Cleaner Dirty. Water in fuel tank. Carburetor idle mixture set incorrectly. Points and plugs worn or not set properly. Governor incorrectly adjusted.	Clean or replace air cleaner. See page 25. Remove fuel tank to drain, replace fuel filter. Set idle mixture. See page 15. Adjust or replace. See page 27. Adjust governor settings. See page 15.
Excessive oil consumption.	Engine running too hot. Using wrong weight of oil. Too much oil in crankcase.	Clean engine fins. See page 29. Clean transmission oil cooler. See page 23. Change to correct weight oil. See page 25. Check oil level according to instructions on page 23.
OIL light comes on.	Low oil supply. Crankcase oil too light or diluted.	Add oil to full mark. See page 23. Change oil, use correct grade and weight. See page 25.
Exhaust is black or smoky.	Air filter element dirty. Fuel mixture too rich.	Clean or replace filter element. Be sure choke opens fully when it is pushed way in. Set carburetor idle adjustment. See page 15.
Alternator does not charge.	Protective fuse blown. Alternator or regulator defective.	Check fuse in wiring at right front corner of engine. Replace with 30 Amp. fuse. See figure 28. Have your Simplicity dealer replace.
Engine runs, tractor will not drive with full power.	3-speed transmission not in gear. Parking brake ON. Transmission fluid cold. Transmission low on fluid Main drive belts are slipping. Transmission filter plugged.	Put 3 speed transmission in gear. Release parking brake. Allow 5-10 minutes to warm up. Add transmission fluid. See page 23. Adjust clutch belt tension and free travel. See page 16. Replace filter. See page 29.
Tractor creeps forward or back with hydrostatic control in Neutral.	Hydrostatic control out of adjustment.	Adjust hydrostatic neutral setting. See page 17.
Brake will not hold.	Brakes need adjusting. Worn brake linings.	Adjust brake linkage. See page 18. Have your Simplicity dealer replace linings.
Transmission HOT light comes on.	Transmission fluid cooler may be plugged or dirty. Operating tractor in too high a gear.	Clean fluid cooler. See page 23. Shift to next lower gear and wait for light to go out.
Tractor drive clutch will not engage.	Too little clutch free travel.	Adjust clutch free travel. See page 16.

ADJUSTMENTS

Most of the adjustments described here are easy to perform. Some of the adjustments require a little mechanical know-how and some special tools to do them well. You may wish to have your Simplicity dealer make some or all of the adjustments as they are required; however, we have given instructions for them here as a convenience to you should you wish to make them yourself. Adjustments which are suggested as part of Scheduled Maintenance are explained under the appropriate heading in the Maintenance section which begins on page 23.

CARBURETOR

See figure 6. The carburetor has a fixed main fuel jet which does not require any adjustment. The idle jet (A) which affects engine operation at low speed is adjustable. Under normal circumstances, factory carburetor adjustments should not be changed. **CAUTION: SINCE THE CARBURETOR ADJUSTMENT MUST BE MADE WITH THE ENGINE RUNNING, BE SURE THE HYDROSTATIC TRANSMISSION CONTROL LEVER AND THE 3 SPEED GEAR TRANSMISSION LEVER ARE IN NEUTRAL BEFORE LEAVING THE TRACTOR SEAT. SET THE PARKING BRAKE AND INSURE ALL POWER TAKE OFF SWITCHES ARE IN THE "OFF" POSITION. KEEP YOUR HANDS AND ANY CLOTHING AWAY FROM THE FRONT POWER TAKE OFF PULLEY.** Forcing the idle needle against its seat will damage it. The idle needle does not completely shut off fuel when turned fully in. If the idle adjustment has been disturbed, turn the idle needle clockwise gently to its seat, then (counter-clockwise) off its seat 1 to 1-1/2 turns to permit starting the engine. Readjust as follows:




Figure 6. Carburetor and governor adjustments as seen from above engine.

1. Allow the engine to run at least 10 minutes to warm it up thoroughly.
2. Move the engine speed control to the **SLOW** position. The engine should run about 1200 (RPM) revolutions per minute. The engine has been set to idle at 1200 RPM at the factory. If the governor needs adjusting, use a tachometer to adjust the governor as explained on page 15.
3. Best adjustment of the idle mixture can be made with the engine running at 1000 RPM rather than 1200 RPM. The engine should run at 1000 RPM when the minimum speed control screw (B) is pushed down to touch the manifold.
4. Turn the idle needle (A) out (counter-clockwise) until the engine begins to slow down or run unevenly. Remember that position.
5. Turn the idle needle in (clockwise) past the position where the engine runs smoothly until it begins to slow or run unevenly.
6. Turn the idle needle out one half way between the two locations found in step 4 and 5.
7. Move the speed control lever toward the **FAST** position quickly. If the engine accelerates evenly, the adjustment is correct. If the engine hesitates, turn the idle needle out counter-clockwise about 1/8 of a turn and try again. If it still does not accelerate evenly, check the governor adjustments below.

GOVERNOR ADJUSTMENT

Figure 6. A tachometer is required to set the governor correctly. **CAUTION: SINCE THE GOVERNOR ADJUSTMENT MUST BE MADE WITH THE ENGINE RUNNING, BE SURE THE HYDROSTATIC TRANSMISSION CONTROL LEVER AND THE 3 SPEED GEAR TRANSMISSION LEVER ARE IN NEUTRAL BEFORE LEAVING THE TRACTOR SEAT. SET THE PARKING BRAKE AND INSURE ALL POWER TAKE OFF SWITCHES ARE IN THE "OFF" POSITION. KEEP YOUR HANDS AND ANY CLOTHING AWAY FROM THE FRONT POWER TAKE OFF PULLEY.**

LOW SPEED

1. Start the engine and move the speed control lever to the **SLOW** position.
2. Using a screwdriver, turn the minimum speed control screw (B) clockwise to increase or counter-clockwise to decrease engine speed as required until the engine runs at 1000 RPM (revolutions per minute) when the carburetor throttle is held closed.
3. Readjust the idle mixture according to the instructions on page 15 while the engine is running at 1000 RPM.
4. Check the adjustment made in step 2 and readjust the minimum idle speed if necessary.
5. Adjust the nuts at (C) so the engine will run at 1200 RPM with the engine speed control lever in the **SLOW** position. To increase the engine speed turn the nuts clockwise. To decrease engine speed turn the nuts counter-clockwise.
6. Tighten the two nuts against each other securely so they will stay in position.

HIGH SPEED

1. Move the engine speed control all the way ahead to the **FAST** position.
2. Turn the adjustment nuts (D) clockwise or counter-clockwise as required so the engine runs between 3800 and 3850 RPM (revolutions per minute). **CAUTION: DO NOT EXCEED 3850 RPM.**
3. Tighten the two nuts (D) against each other securely so they will stay in position.

TRACTION CLUTCH BELT TENSION

See figure 7. The clutch (drive belt) tension is determined by the distance from the casting at the base of the clutch tension spring to the top of the spring. This distance (A) shown in figure 7 should be 8 inches. As the belts wear, this distance may increase, causing tension on the belts to decrease and allowing them to slip. To adjust the main drive belt tension, proceed as follows:

1. Raise the tractor hood.
2. See figure 8. Remove the screws (A) at each end of the transmission oil cooler and raise the left end of it to expose the main drive belt tension adjustment.
3. Be sure the clutch is released and has fully returned to the engaged (pedal out) position.
4. Use a ruler or tape graduated in inches to measure the distance (A) from the casting surface to the top of the spring as shown in figure 7.
5. If the spring height (A) is greater than 8 inches, turn the hexagon nut (B) above the spring clockwise until the distance is 8 inches. If the height is less than 8 inches turn the hexagon nut counter-clockwise.
6. The belt stop (figure 9) should be adjusted whenever the traction clutch belt tension is adjusted or if the clutch does not disengage completely when the clutch pedal is depressed. Using a 1/2" wrench, loosen the capscrew (A) and adjust the belt stop (B) so there is 1/16" clearance between the belt stop and each belt when the clutch pedal is released. Tighten the capscrew securely.




Figure 7. Traction clutch belts located under oil cooler.




Figure 8. Transmission oil cooler as seen from above tractor.

7. Replace the oil cooler and secure it in place with the washers and screws removed earlier.

CLUTCH PEDAL FREE TRAVEL

Clutch pedal free travel is the distance which the clutch pedal can be easily pushed downward with finger pressure. This distance should be 1-1/2 to 1-3/4 inches when measured as shown in figure 10. If the distance becomes less than 1 inch or more than 1-3/4 inches, readjust the clutch pedal free travel as follows:

1. See figure 11. Using a 3/8" wrench, remove the 10 capscrews (A) holding the dust shield (B) to the underside of the tractor frame.
2. See figure 12. Using a 9/16" wrench, turn the lock nut (A) counter-clockwise to increase the amount of free travel or clockwise to decrease the free travel. Alternately check the amount of free travel and turn the lock nut until the




Figure 9. Belt stop located under oil cooler.




Figure 10. Measurement of clutch pedal free travel as seen from left of tractor.

amount of free travel measures 1-1/2 to 1-3/4 inches.

3. Replace the dust shield and 10 capscrews on the bottom of the tractor and tighten the capscrews securely.




Figure 11. Dust shield on underside of tractor frame.




Figure 12. Clutch pedal free travel adjustment.

HYDROSTATIC TRANSMISSION NEUTRAL ADJUSTMENT

If the tractor has a tendency to move forward or rearward when the hydrostatic transmission control lever is in the **NEUTRAL** position, the Neutral adjustment should be made. All clockwise and counter-clockwise directions given are as you look down on the turnbuckle from above the tractor frame. Proceed as follows:

1. See figure 13. Using a 3/8 inch wrench remove the six capscrews (A) and cover plate (B) from the top of the frame in front of the tractor seat.
2. See figure 11. It is not necessary to remove this shield, but the locking nuts on the ends of the turnbuckle are more easily reached from below. Using a 3/8" wrench remove the 10 capscrews (A) holding the dust shield (B) to the underside of the tractor frame.




Figure 13. Cover plate over frame as seen from left side of tractor.




Figure 14. Hydrostatic transmission neutral adjustment as seen from above tractor seat.

3. See figure 14. Using two 3/4 inch wrenches, loosen the locking nuts (A) on either side of turnbuckle (B). To loosen the lock nuts hold the turnbuckle stationary with one wrench and use the other to turn the locking nuts counter-clockwise to loosen them.
4. While sitting on the tractor seat start the engine and let it run at a slow idle.
5. Place the gear transmission in first gear.
6. Place the hydrostatic transmission control lever against the **NEUTRAL** stop.
7. If the tractor does not move, increase the engine speed until it does.
8. Stop the engine. **CAUTION: DO NOT ATTEMPT TO MAKE ANY ADJUSTMENT OF THE TURNBUCKLE WHILE THE ENGINE IS RUNNING. THE REAR POWER TAKE OFF SHAFT AND MAIN DRIVE SHAFT ARE TURNING AT HIGH SPEED NEAR THE TURNBUCKLE.**
9. If the tractor moved forward, with the hydrostatic control lever in the notched neutral position, turn the turnbuckle counter-clockwise (as viewed from above) about 1/2 turn. If the tractor moved rearward, turn the turnbuckle clockwise.
10. Alternately run the engine and adjust the turnbuckle until the tractor does not move at all when the engine is running at full speed.
11. Shut off the engine. Use one 3/4" wrench to prevent the turnbuckle from turning while tightening the two locking nuts at either end against it with the other 3/4" wrench.
12. Check your adjustment once again by running the engine to make sure you didn't change the adjustment while tightening the locking nuts.
13. Replace the cover plate and tighten the six capscrews securely in place.
14. Replace the dust shield and 10 capscrews if it was removed (Step 2).

NEUTRAL SAFETY STARTING SWITCH

If the engine starter will not actuate or will actuate when the hydrostatic transmission control lever is not in the **NEU-**



Figure 15. Neutral start safety switch as seen from beneath tractor.

TRAL position, the neutral safety starting switch may need adjusting. Adjust it as follows:

1. See figure 11. Remove the ten capscrews and dust shield from the underside of the tractor frame.
2. Place the hydrostatic transmission control lever in the notched **NEUTRAL** position.
3. See figure 15. The Neutral Safety Switch can be moved back and forth by turning the two nuts (A) counter-clockwise or clockwise and up and down by sliding it in the mounting bracket (B).
4. Place a film of grease on the cam (C) where it contacts the switch.
5. Adjust the safety switch so it is centered on the cam surface (C) and the end of the switch moves about 1/8 inch when the control lever is moved.
6. Tighten the two nuts (A) against the mounting bracket.
7. Check the adjustment by starting the tractor.
8. Replace the dust shield and 10 hex capscrews and tighten the capscrews securely.

BRAKE ADJUSTMENT

See figure 16. You should adjust the brakes if they become ineffective or if the travel of the two brakes becomes different preventing them from braking the two wheels simultaneously when the brake pedals are locked together. To adjust the brakes, proceed as follows:

1. See figure 13. Using a 3/8" wrench, remove the 6 hex headed screws from the frame cover and remove the cover from the tractor.
2. Be sure the brake pedal locking pin is moved to the left, so the brakes can be applied individually.
3. See figure 17. Adjust the left brake first. You will need two 9/16" open end wrenches. Use one wrench to hold the turnbuckle (A), the other to loosen the lock nuts (B) at either end of the turnbuckle. Turn the turnbuckle counter-clockwise (as you stand behind it looking toward the front of the tractor) to tighten the brake. Alternately turn the turnbuckle and check the brake travel until the brake travel




Figure 16. Brake pedal free travel measured on right side of tractor.

as measured in figure 16 is 1-1/4 inches. While holding the turnbuckle (A) with one wrench, tighten the two nuts (B) at either end of the turnbuckle against the turnbuckle to lock it in place.

4. Depress the left brake pedal and lock it in place with the parking brake lock. If the parking brake will not lock in place you may have to increase the amount of brake pedal free travel by turning the turnbuckle clockwise. With the parking brake lock set to hold the left brake pedal down, follow the procedure described in step (3) to adjust the right brake pedal. Alternately depress and tighten it until it is even with the left brake pedal when depressed. Checking the adjustment of the right brake pedal in this manner will not only give it the required 1-1/4 inches of free travel, but also insure that the two brakes will be activated at the same time when they are locked together. Tighten the locking nuts in place on either side of the turnbuckle.

5. Replace the cover over the frame and tighten the 6 hex headed screws securely in place.

SEAT ADJUSTMENT-STANDARD FIVE POSITION SEAT

See page 7 , for adjusting the optional spring mounted, lever adjusted seat. The five position standard equipment seat (figure 18) can be adjusted front to rear a total distance of 4 inches. Adjust it as follows:

1. Loosen, but do not remove, the two nuts marked (A).
2. Remove the two nuts, washers and bolts at (B).
3. Slide the seat forward or back to the desired position and line up the holes in the seat frame.
4. Replace the two bolts, washers and nuts removed in step (2) and tighten them securely.
5. Securely tighten the two nuts (A) loosened in step (1).




Figure 17. Brake adjustment turnbuckles as seen from above tractor frame.

WHEEL TREAD ADJUSTMENT

The Simplicity 4040 can be equipped with several different tire combinations. Figures 19 and 20 show the tire combinations and the widths as installed on the tractor. The Agricultural tires can be installed with either the rim in or out to vary tread width. **NOTE: WHEN CHANGING THE RIM POSITION OF THE REAR AGRICULTURAL TIRES TO ADJUST THE TREAD WIDTH, THE LEFT TIRE MUST BE PUT ON THE RIGHT AND THE RIGHT TIRE ON**




Figure 18. Standard seat adjustment as seen from right side of tractor.







Figure 19. Wheel and tire option available for the 4040.



TIRE			TIRE DIAMETER	VALVE STEM FACING OUT			VALVE STEM FACING IN		
NAME, SIZE AND LOCATION				A	B	C	A	B	C
AGRICULTURAL	8 x 16	REAR	31-3/4"	43-1/4"	24-3/8"	33-13/16"	48"	29-1/8"	38-1/2"
AGRICULTURAL	4 x 12	FRONT	21-1/4"	41-1/2"	32-3/16"	36- 7/8"	47-3/16"	37-13/16"	42-1/2"
TURF	29 x 12-15	REAR	29"	50-1/2"	29-3/16"	38-5/16"			
TURF	20 x 10-8	FRONT	19-1/2"	47-1/4"	31-7/8"	39-1/2"			
HIGH FLOTATION	31 x 15.5-15	REAR	31-3/4"	56-1/2"	26-5/8"	41-1/2"			
HIGH CAPACITY	6 x 9	FRONT	21-1/4"	46"	33"	39-1/2"			



When changing the position of the rear agricultural tires to adjust the tread width, the left tire must be put on the right and the right tire on the left so the tire treads grip in the proper direction. Check the arrow on the outside of the tire for correct rotation of the tire.

Figure 20. Table of tire tread widths.

THE LEFT SO THE TIRE TREADS GRIP IN THE PROPER DIRECTION. Check the arrow on the outside of the tire which indicates the proper rotation of the tire during forward travel.

WEIGHTING WITH CALCIUM CHLORIDE

A convenient means of adding weight to the rear wheels of the 4040 tractor is to put a calcium chloride solution in the tires. The data given below will give a solution having 3.5 pounds of calcium chloride per gallon of water which will be slush free to -12°F and will freeze solid at -52°F. The

amounts given will fill one Agricultural 8-16 tire to 75% of its capacity.

GALS. WATER	POUNDS CHCL²	TOTAL WEIGHT
9.5	33	111 pounds

Calcium Chloride solution of the proportions shown here can also be added to the Turf and High Flotation tires; however, it is not normally practical as weighting these tires lessens the flotation capability for which they are designed. Wheel weights for adding weight to the tractor are also available from your Simplicity dealer as an accessory. See page 32.

MAINTENANCE

Your Simplicity 4040 has been designed and manufactured to give you many years of dependable operation. In order for it to give you efficient, trouble free service over a long period of time, the maintenance operations listed here must be performed on a regular basis. The optional hourmeter which may be either factory or field installed provides an accurate method of determining when these services need to be performed. A wide variety of attachments and accessories permit use of your tractor throughout the year. **BECAUSE YOUR TRACTOR IS A MULTI-SEASON TOOL, IT IS VERY IMPORTANT TO SERVICE THE ENGINE FOR THE SEASON IN WHICH IT WILL BE OPERATED.** Be sure to change to winter grade oil before making cold weather starts. Whenever you are checking fluid levels in any area of the tractor, the readings will be much more accurate if the tractor is setting on level ground. We have provided the Scheduled Maintenance Chart on page 24 as a convenient means for you to know which services should be performed at various times. You should, of course, refer to the detailed explanation of how to perform each maintenance task until you are familiar enough with it to perform it correctly from memory.

ORDERING REPLACEMENT PARTS

Replacement parts required for performing maintenance services or for repair work should be purchased from your Simplicity dealer. When ordering parts be prepared to give him the tractor and engine identification numbers. If you have not already recorded these numbers on the inside front cover of this manual, we suggest that you do so now for convenient future reference.

EVERY 5 HOURS OF OPERATION

INSPECT THE TRACTOR AND ENGINE: Make a general inspection of the tractor and engine looking for loose bolts, oil leaks, low tire pressures, etc. A few minutes spent correcting a small problem could prevent a costly breakdown later.

CHECK ENGINE CRANKCASE OIL LEVEL: See figure 22. If the engine has been running, allow a minute or two for the oil to drain down into the crankcase before checking the oil level. Proceed as follows:

1. Turn the engine oil filler cap-dipstick to the left and lift it out.
2. Wipe the oil from the dipstick with a clean cloth.
3. Replace the filler cap-dipstick in the filler pipe and turn the cap to the right locking it in position.
4. Remove the filler cap-dipstick and check the oil level on the dipstick.
5. If the oil is below the 1 quart line shown in figure 22 add enough oil to bring the oil level up to the **FULL** mark on the dipstick. Use the same grade and weight of oil which is already in the engine. (Above 30°F, SAE 30; Below 30°F, 5W30).
6. Replace the filler cap-dipstick and tighten it securely.

CHECK TRANSMISSION OIL (FLUID) LEVEL:

See figure 23. The hydrostatic transmission, the tractor hydraulic system and the three speed gear transmission all use oil from the 3 speed transmission case. To check the oil level, turn the check cock (A) shown in figure 23 counter-clockwise two turns or until oil runs out. If no oil runs out of the open check cock, remove the oil filler plug (B) and add type A, type F, or Dexron automatic transmission oil until oil drips from the check cock. Tighten the check cock finger tight.

CLEAN TRANSMISSION OIL (FLUID) COOLER:

See figure 24. Inspect the oil cooler and if necessary remove any dirt, chaff, or oil which may decrease the efficiency of the cooler. Dirt and chaff collected on the outside of the cooler can usually be brushed off after the engine has stopped. Be careful not to bend the cooler fins. If grass, chaff, or dirt collect between the fins, it may be necessary to remove the capscrews at each end of the cooler (figure 8, item A) and raise the left side of the cooler. Air or water pressure can be used to blow the dirt out. A non-flammable solvent should be used to remove any oil which may collect on the outside of the cooler. In warm or dusty operating conditions or when mowing dry grass, the cooler may need to be cleaned more often to prevent foreign material from restricting air flow through it.

EVERY 25 HOURS OF OPERATION

CHECK THE BATTERY WATER LEVEL: See figure 25. The battery water level may be checked by looking through the cover hole (A) at the Delco eye (B). When the battery is low on water, the Delco eye will light up. The Delco eye must be kept clean and installed in the second cell from the positive battery terminal. The battery cover may be removed to check each cell individually and for adding water. When the battery is in use water evaporates from it. **NEVER ALLOW THE WATER LEVEL IN THE BATTERY TO GET BELOW THE TOP OF THE PLATES.** Fill the battery to the marking ring with distilled water. If distilled water is not available, clean tap water may be used. Water evaporates faster under high operating temperatures. Check the battery more often in warm weather.

CHECK TIRE PRESSURE: Tires will last longer and perform better if they are kept properly inflated. Required pressures vary depending on the tire size. Use the chart below for determining the correct inflation pressure in pounds per square inch for the tires on your tractor

FRONT	
TIRE SIZE	PRESSURE
Turf — 20 - 8.00 - 10	10 PSI
Agricultural — 4.00 - 12	28 PSI
High Capacity — 6.00 - 9	40 PSI
REAR	
Turf — 29 x 12 - 15	8 PSI
Agricultural — 8 x 16	10 PSI
High Flotation — 31 x 15.50 - 15	6 PSI

SCHEDULED MAINTENANCE CHART

Service Required	Page	After each cycle of indicated hours					
		5	25	50	100	200	400
Inspect the tractor and engine	23	●					
Check Engine crankcase oil level	23	●					
Check transmission oil level	23	●					
Clean transmission oil cooler *	23	●					
Check battery water level *	23		●				
Check tire pressure	23		●				
Lubricate grease fittings *	25			●			
Clean engine air filter *	25			●			
Change engine oil * (First change 25 hours)	25			●			
Replace engine oil filter *	26				●		
Check traction clutch belt tension	26				●		
Change spark plugs	26				●		
Check drop housing oil level	27					●	
Replace fuel filter *	27					●	
Change breaker points	27					●	
Clean crankcase breather valve *	28					●	
Clean governor linkage *	28					●	
Clean engine fins *	29					●	
Replace air cleaner element *	29					●	
Change transmission oil	29						●
Replace transmission oil filter (FIRST CHANGE 25 HOURS)	29						●
Repack front wheel bearings	29						●
Remove carbon and lead deposits	30						●
Set engine valve tappet clearance	31						●

* More often under dusty and/or hot weather operating conditions.

Figure 21. Scheduled Maintenance Chart.




Figure 22. Engine oil filler cap - dipstick removed.

EVERY 50 HOURS OF OPERATION

LUBRICATE GREASE FITTINGS: The basic tractor has three grease fittings which require lubrication. One is located on each of the two front wheel spindles (Figure 37, item H) and one is on the front axle pivot (Figure 26, item B). There are two grease fittings on the optional 3-point hitch (Figure 53, item D). Lubricate each grease fittings with 5 shots of general purpose automotive grease every 50 operating hours. When operating under extremely wet or dusty conditions, lubricate more often.

CLEAN ENGINE AIR FILTER: See figure 27. The air cleaner element (A) should be removed and cleaned every 50 hours or more often under dusty operating conditions. Proceed as follows:

1. Raise the tractor hood.
2. Using the palms of both hands, push the rubber lips down as shown in figure 27.
3. Lift the air filter element upward to remove. **CAUTION: NEVER OPERATE THE ENGINE WITHOUT THE AIR FILTER ELEMENT SEALED IN PLACE.** Be careful not to allow dirt or other foreign mixtures to drop down into the carburetor.




Figure 23. Transmission check cock and filler plug as seen from behind tractor.




Figure 24. Transmission oil cooler raised for cleaning.

4. Turn the air filter element upside down and tap it lightly to remove the dirt from it.
5. Replace the air filter element insuring that it is properly seated.
6. Using the palms of both hands, lift the rubber lips up around the element, insuring the rubber seals tightly around the air filter element.
7. Lower the hood and lock it in place.

CHANGE ENGINE OIL: Every 50 hours or more often under dusty operating conditions change the engine oil using an oil with a designation of SD/CC, MS, MS/DG or MS/DM.

TEMPERATURE

Below 30°F
Above 30°F

GRADE

SAE 5W30
SAE 30

1. Operate the engine at least 10 minutes or until it is warm so the oil will drain freely.
2. See figure 26. Remove the drain plug (A) from the bottom of the engine base and allow the oil to drain.




Figure 25. Battery located at the front of tractor under the hood.




Figure 26. Engine oil drain plug and axle grease zerk under front of tractor.

3. After the oil has completely drained from the engine, replace the drain plug and tighten it securely.
4. See figure 22. Pour 3-1/2 quarts of oil (4 quarts if the oil filter has been changed) into the engine through the oil filler pipe, being careful not to allow any dirt or foreign material to contaminate the oil.
5. Check the oil level. It should show up to the **FULL** mark on the dipstick.
6. Replace the oil filler cap - dipstick, start the engine, and check for leaks.

EVERY 100 HOURS OF OPERATION

REPLACE ENGINE OIL FILTER: (See figure 28) Every 100 hours or every other time the engine oil is changed, the oil filter (A) should be replaced. Replace the oil filter after the oil has been drained during an oil change, but before adding the new oil. Proceed as follows:

1. Remove the filter by turning it counter-clockwise using a filter wrench.




Figure 27. Air cleaner and fuel filter as seen from right of tractor.




Figure 28. Right front cover of engine.

2. Wipe the drippan located below the filter dry.
3. Install the foam strip over the new filter (Figure 28, item B) to prevent loss of cooling air.
4. Place a coating of oil on the filter sealing gasket.
5. Install the new oil filter finger tight plus 1/4 to 1/2 turn.
6. After replacing the engine oil, start the engine and run at idle speed until the oil light goes out.

Check around the oil filter for leaks. Any oil coming from the drain tube below the filter probably indicates a poor seal between the engine and the filter base. If leakage is detected, loosen the filter and retighten as instructed in step 5. If the leak does not stop, remove the filter and inspect the filter seat. Replace the filter with a new one if the seal shows any damage.

CHECK TRACTION CLUTCH BELT TENSION:

See figure 7. Every 100 hours or anytime you suspect the clutch (drive belts) may be slipping, the height of the belt tension spring should be checked as shown in figure 7. If the distance from the casting at the base of the spring to the top of the spring is not 8 inches with the clutch disengaged (pedal released), readjust the belt tension as described on page 16 of this manual. The clutch free travel should be checked each time the traction clutch belt tension is adjusted (page 16).

CHANGE SPARK PLUGS: See figure 29. Remove the two spark plugs from the engine and install new ones every 100 hours. Use Champion H-8 or equivalent. Before installing new plugs, set the gap at .025 inch.




Figure 29. Setting spark plug gap.

EVERY 200 HOURS OF OPERATION

CHECK DROP HOUSING OIL LEVEL: See figure 30. Remove the oil level plug (A) from each of the two drop housings to check the oil level. The oil should be even with the lower threads in the plug hole. If oil must be added to bring the oil level up to the threads, add SAE 90 transmission grease through the check plug hole. If it should be necessary to drain the drop housings the drain plug (B) may be removed.

REPLACE FUEL FILTER: See figure 27. The fuel filter (B) is located in the fuel suction line between the fuel tank and fuel pump. **CAUTION: DO NOT REMOVE THE FUEL LINES FROM THE FUEL FILTER WHEN THE ENGINE IS HOT.** After determining that the engine is cool, squeeze the spring clamps on each side of the filter and remove the fuel filter. Install the new filter, fastening the hoses at each end with the spring clips.




Figure 30. Drop housing shown from rear of tractor.




Figure 31. Engine heat shield.

CHANGE BREAKER POINTS: To maintain maximum efficiency, the ignition breaker points should be changed every 200 operating hours. Proceed as follows:

1. To help prevent injury, remove the ignition key from the tractor.
2. See figure 31. Remove the 4 screws (A) and lift the heat shield off the engine.
3. Remove the two screws (B) and remove the cover (C) from the breaker point box.
4. See figure 8. Remove the capscrews at each end of the oil cooler and raise the left end of the cooler to expose the engine cooling fan.
5. Remove the two spark plugs so the engine can be easily rotated by hand as required in a later step. If the spark plugs have not been changed within the last 100 hours of operation, replace them with new ones after the breaker points and ignition timing have been set.
6. See figure 32. Remove the two mounting screws marked (A) and pull the points out of the box just far enough so screw (B) can be removed.
7. After removing screw (B) replace the points with a new set. Replace, but do not tighten the two mounting screws (A).




Figure 32. Breaker point box.




Figure 33. Timing access hole in engine air shroud.

8. Rotate the engine clockwise (as viewed from the rear) by turning the engine cooling fan by hand until the points open. The flywheel should be about 1/4 turn after top center. Turn the screw (C) until the distance between the points measures .020" with a flat thickness gauge.
9. Tighten the mounting screws securely and recheck the distance between the points to be sure it is .020".
10. Set the ignition timing as outlined in the following section.
11. Replace the breaker point cover, heat shield and oil cooler and tighten all screws securely

SETTING IGNITION TIMING: The engine is equipped with an automotive type battery ignition system. Both spark plugs fire simultaneously, thus the need for a distributor is eliminated. Spark advance is set at 20°BTC (before top center) and should be maintained for best performance. Ignition timing should be checked after point replacement or if poor engine performance is noticed. Proceed as follows:

1. To accurately check the ignition timing, use a timing light when the engine is running. Connect the timing light according to its manufacturers instructions. Either spark plug may be used as they fire simultaneously.
2. See figure 33. Remove the plastic plug from the timing hole (A).
3. See figure 33. Place a white chalk or paint mark on the 20° timing mark. **CAUTION: SINCE THE ENGINE MUST BE RUNNING WHEN THE OPERATOR IS NOT ON THE TRACTOR SEAT, BE SURE THE GEAR TRANSMISSION IS IN NEUTRAL AND THE PARKING BRAKE SET BEFORE STARTING THE ENGINE.**
4. Start the engine and check the timing. The engine should be running at idle speed when checking the timing.
5. See figure 31. If adjustment is required, remove the heat shield and breaker box cover as described in steps 2 and 3 of the preceding section on Changing the Breaker Points.
6. See figure 32. If the timing is very far off, attain an approximate setting by loosening the mounting screws (D) and shift the breaker box (and spacer if used) to align the refer-

- ence marks (E) on the crankcase and breaker box (or spacer).
7. Turn the engine over slowly (the oil cooler will have to be raised to do this) in the direction of crankshaft rotation (clockwise) until the TC marks on the flywheel and the gear cover are exactly in line. You can see this by looking through the opening created by raising the oil cooler.
8. Slightly loosen the two mounting screws (A) in figure 32 to adjust the point gap to .020".
9. Start the engine and check the timing. With the two screws (D) slightly loose, the breaker point box can be moved left to advance the spark or right to retard the spark (as you face the breaker point box from the front of the engine).
10. Securely tighten all screws and replace the timing plug, breaker point cover, heat shield, etc.

CLEAN CRANKCASE BREATHER VALVE: See figure 34. The crankcase breather valve should be removed and cleaned every 200 hours or more often under dusty operating conditions. Proceed as follows:

1. Remove the hose clamp (A) and hose from the breather.
2. Turn the clamp screw (B) counter-clockwise to loosen the clamp.
3. Remove the clamp (C), breather cover (D), and breather filter mesh (E).
4. Wash the breather cover assembly and filter mesh in a non-flammable solvent.
5. Replace the filter mesh, breather cover, clamp and screw. Tighten the screw securely.
6. Replace the hose and hose clamp.

CLEAN GOVERNOR LINKAGE: See figure 34. Every 200 hours or more often under dusty operating conditions, the governor linkage (F) should be cleaned. Wait until the engine cools to work on the linkage. An air hose may be used




Figure 34. Crankcase breather valve and governor linkage located on top of engine.

to blow dust and dirt away from the linkage. If the linkage is coated with grease or oil, a nonflammable solvent and soft brush should be used.

CLEAN ENGINE FINS: See figure 28. The engine cooling fins should be cleaned every 200 hours or more often if material accumulates in them. Proceed as follows:

1. Use a 7/16" wrench to remove the capscrews (C) from the air shrouds (D) on each side of the engine.
2. Remove the air shrouds from each side of the engine.
3. Use air pressure or a brush to remove all foreign material from between the cooling fins.
4. Replace the air shrouds and tighten the capscrews securely in place.

REPLACE THE AIR CLEANER ELEMENT: See figure 27. The air cleaner element should be replaced every 200 hours or oftener if dusty operation conditions cause it to become too dirty to be cleaned effectively. A new filter element should be purchased from your Simplicity dealer. Be sure the rubber lips are sealed around the new filter before operating the engine.

EVERY 400 HOURS OF OPERATION

CHANGE THE TRANSMISSION OIL (FLUID): See figure 35. **DO NOT RUN THE ENGINE WITHOUT OIL IN THE TRANSMISSION.** The transmission case is divided into two compartments. Both the oil temperature sending unit (A) and the pipe fitting (B) on the front of the transmission must be removed to drain the transmission completely. Warm oil will drain best. The tractor should be operated at least 1/2 hour to warm the oil before draining the transmission. Proceed as follows:

1. Park the tractor on a level surface, stop the engine and set the parking brake.
2. Remove the wire from the oil temperature sending unit (A).
3. Using a 15/16" wrench remove the oil temperature sending unit.
4. Remove the spring clamp and hose from the pipe fitting (B).
5. Using a 15/16" wrench, remove the pipe fitting from the transmission.
6. After the oil has drained completely, replace the pipe fitting, hose and spring clamp and the oil temperature sending unit and wire.




Figure 35. Front of transmission as seen from beneath the tractor with dust shield removed.

7. See figure 23. Remove the transmission filler plug (B) and fill the transmission with type A, type F, or Dexron automatic transmission oil to the check cock. About 6 quarts of oil will be required to fill the transmission.

CHANGE THE TRANSMISSION OIL FILTER:

Change the transmission oil filter after the first 25 hours of operation. After the first change, the filter need only be changed every 400 hours or whenever the transmission oil is changed.

1. See figure 36. Remove the oil filter (A) by turning it counter-clockwise.
2. Wipe the sealing surface of the mounting bracket clean.
3. Place a film of transmission oil on the filter sealing gasket.
4. Install the new filter by turning it clockwise until hand tight.
5. When the transmission has been filled with oil, start the engine and check for leaks.
6. Stop the engine and recheck the transmission oil level to be sure it is full.

REPACK FRONT WHEEL BEARINGS: Before disassembling the front wheel bearings, you should purchase new grease seals for them from your Simplicity dealer.

1. See figure 37. Block up the front axle of the tractor so the wheel you are to work on is not supporting the tractor.
2. Use a pliers or claw hammer to remove the dust cover (A) from the wheel hub (B). The dust cover will be easier to get off if the wheel is removed.
3. Remove the cotter pin (C).
4. Use a 1-1/8 inch wrench to remove the nut (D) by turning it counter-clockwise.
5. Remove the washer (E) and outer bearing (F) and pull the hub off the axle.
6. Use a large drift punch to push the seal (G) out of the hub. You should keep the two bearings separate so you can put them back in their original place.
7. Wash the bearings, axle and bearing housing with a nonflammable solvent and wipe dry.




Figure 36. Transmission oil filter on right side of tractor frame.




Figure 37. Right front spindle and axle assembly.

8. Using the palm of your hand, force a good quality wheel bearing grease into each of the bearings.
9. Place a film of grease on the axle shaft.
10. Put the inner bearing in place in the bearing housing and press a new grease seal (G) in place as it is shown in figure 38.
11. Being careful not to damage the grease seal, slide the wheel hub onto the axle shaft.
12. Install the outer bearing, washer, and nut over the axle shaft.
13. Alternately tighten the nut and spin the wheel until a drag is felt on the wheel. Back the nut out until no drag is felt on the wheel. There should be no play in the wheel.
14. Install the cotter pin in the nearest slot available. Bend the ends of the cotter pin over so it will not fall out.
15. Replace the dust cover (A).




Figure 38. Pressing grease seal into front wheel hub.




Figure 39. Cylinder head bolt tightening sequence.

REMOVE CARBON AND LEAD DEPOSITS: To remove carbon and lead deposits, the cylinder heads must be removed. The work should be done by a competent mechanic. Remove the heads only when the engine is at room temperature, (about 70°) as they may warp if removed when hot. Proceed as follows:

1. See figure 28. Use a 7/16 inch wrench to remove the two capscrews (C) from each of the air shrouds over the two cylinder heads.
2. Remove the air shrouds (D).
3. See figure 39. Use a 1/2" socket wrench to remove the cylinder head bolts. Turn them counter-clockwise to remove them.
4. After removing the cylinder heads, the carbon can be cleaned from them with a fine wire hand brush. Do not use an electric brush as too much metal could be removed. Be especially careful not to damage the outer sealing edges where the gasket fits. The heads are made of aluminum and can be damaged by careless handling.
5. Use new head gaskets and clean both the block and cylinder heads thoroughly where the gasket rests.
6. Place one head in position on the cylinder block and install the head bolts, placing the longer bolts through the holes marked 1, 2, 3, 4 and 7 in figure 39.
7. A torque wrench should be used to tighten the head bolts. This should be done when the engine is at room temperature. Use the tightening sequence shown in figure 39. Tighten number 1 bolt to 5 foot pounds torque, then number 2, etc. After all bolts are tightened to 5 foot pounds, repeat the sequence, tightening each bolt to 10 foot pounds. Repeat the sequence increasing 5 foot pounds each time until each bolt is tightened 29-31 foot pounds. Install the other head and head gasket and tighten the head bolts as outlined in steps 6 and 7.
8. Replace the air shrouds and capscrews removed in steps 1 and 2.
9. After the engine has been run long enough to reach normal operating temperature and allowed to cool to room temperature, the head bolts should be retorqued to 29-31




Figure 40. Engine viewed from right side of tractor.

foot pounds. The retightening should be done before the engine has been run a total of fifty hours.

SET ENGINE VALVE TAPPET CLEARANCE:

The engine is equipped with adjustable valve tappets. The valve tappet clearance should be checked, and adjusted if necessary, every 400 hours. Adjust the valve tappet clearance only after the engine has cooled to surrounding air temperature. A competent mechanic should do the work. Proceed as follows:

1. Remove the ignition key from the tractor to prevent accidental starting.
2. See figure 31. Remove the 4 heat shield mounting screws (A) and heat shield.
3. See figure 40. Disconnect the two fuel hoses (A) at the carburetor and fuel pump and the fuel line (B) between the carburetor and fuel pump.
4. Disconnect the choke cable (C) at the carburetor and the speed control cable (D) and the two governor springs (E) at the governor.
5. Remove screw (F) which holds the ground wire from the breaker point box to the manifold.
6. Use a 9/16" wrench to remove the two manifold mounting cap screws (G) from the manifold.




Figure 41. Adjusting engine valve tappet clearance.

7. Lift off the manifold to expose the valve tappet covers.
8. Use a 7/16" wrench to remove the cap screws from the two valve tappet covers. Remove the valve tappet covers.
9. Remove the spark plugs to make turning the engine easier.
10. See figure 8. Remove the two cap screws (A) and lift the left end of the oil cooler.
11. Use the engine flywheel at the rear of the engine to turn the engine clockwise slowly by hand until the left hand intake valve (as you stand behind the engine facing the engine) opens and closes. Continue to turn the flywheel until the TC mark on it is at the top and lined up with the TC mark on gear cover. This should place the left hand piston at the top of its compression stroke, with both valves closed the position it must be in to get proper valve adjustment for the left cylinder. For each intake (closest to front of engine) valve a .006" thickness gauge should pass freely between the valve stem and valve tappet, a thicker .008" gauge should not. For each exhaust valve, a .015" thickness gauge should pass freely between the valve stem and valve tappet, a thicker .017" gauge should not. To correct the valve clearance, use a 7/16" wrench to turn the adjusting screw clockwise to increase valve clearance or counter-clockwise to decrease clearance. A 9/16" wrench should be used to hold the tappet while turning the adjusting screw. The screw is self-locking and will stay where it is set.
- To adjust the valves on the right hand cylinder, turn the engine over one complete revolution and again line up the mark on the flywheel and the TC mark on the gear cover. Then follow the adjustment given for the valves of the left-hand cylinder.
12. Replace all parts removed in steps 1 through 10. Use new gaskets between the manifold and block. Tighten all mounting screws securely. The manifold bolts should be tightened to 15-20 foot pounds torque.

ACCESSORIES




Figure 42. Rear wheel weight.

The Simplicity 4040 has been designed to do many different jobs under widely varying operating conditions. To make the tractor most effective you may need to use some accessories such as the ones shown here. Contact your Simplicity dealer if you have need for these or other accessories. The Operating Chart on page 10 will help you decide which accessories you need.

REAR WHEEL WEIGHTS

See figure 42. The rear wheel weights are useful in giving extra traction and side hill stability to the tractor. One set of weights which includes one weight for each rear wheel weighs approximately 130 pounds. Up to 3 sets of weights may be installed as shown in figure 42 except when installed on the agricultural tires with the valve stem turned out. Then the outer surface shown in figure 42 should be turned toward the rim. Two bolts, washers and capscrews are provided to attach each weight.

TIRE CHAINS

See figure 43. Tire chains give the tractor added traction, especially on ice or other slippery surfaces. Chains are available for each of the rear tire options available with the Simplicity 4040. Figure 43 shows them installed on the turf tires. **CAUTION: USE TIRE CHAINS WITH CAUTION ON ASPHALT SURFACES.** Install the tire chains as shown in figure 43. The tire pressure should be checked and the tires inflated according to the chart on page 23 before the chains are installed.




Figure 43. Tire chains.

HYDRAULIC CYLINDER

See figure 44. The hydraulic cylinder purchased as an accessory includes the hoses and quick-disconnect couplers. The Front Hydraulic Kit (optional - factory or field installed) is required to use the hydraulic cylinder for front mounted attachments. When connecting the hydraulic cylinder to the hydraulic lines, connect them as shown in figure 44 with the hose to the rod end of the cylinder connected at the coupling designated **ROD END (A)**. The hose to the piston end of the cylinder should be connected to the coupling labeled **PISTON END (B)**. When connecting or disconnecting the quick couplers, push back on the locking ring (C). When using the hydraulic cylinders only one cylinder should be used at a time. The cylinder not being used may be left in position, but the hydraulic couplers must be disconnected so only the one cylinder will move when the hydraulic lever is actuated. **NOTE: A HYDRAULIC CYLINDER DISCONNECTED UNDER PRESSURE (WHILE HOLDING AN ATTACH-**




Figure 44. Hydraulic cylinder.




Figure 45. Front bumper.

MENT IN THE RAISED POSITION) WILL BE DIFFICULT TO CONNECT. See Attachment instructions for the procedure of holding an attachment in the raised position when disconnecting the hydraulic lines.

FRONT BUMPER

See figure 45. The front bumper is helpful in protecting the front end of the tractor from damage. It should be installed as shown in figure 45. The front bumper is required in order to mount the front counterweight (not shown here).

ATTACHMENTS




Figure 46. Snow plow and dozer blade - an example of a front mounted attachment.

The Simplicity 4040 is designed to accept several front, center, and rear mounted attachments. Your Simplicity dealer will be happy to give you specific information on them. We have provided some information here to give you an idea how some of the Simplicity attachments are to be mounted and operated. Also refer to the chart on page 10 of this manual for recommended tractor speed control settings. When using such attachments, you should refer to the attachment owners manual for additional information.

FRONT MOUNTED ATTACHMENTS

See figure 46. Front mounted attachments such as the dozer blade shown require the hitch assembly for front mounted attachments and the front hydraulic kit. The hydraulic cylinder may be removed from the rear lift unit and used to control the front mounted attachments or you may purchase an additional cylinder. If you purchase an additional cylinder, the hydraulic lines to only one of them should be connected at a time. If a hydraulic coupler is disconnected while it is under pressure (an attachment is being held in the raised position by the cylinder), the coupler will be difficult to reconnect. See the attachment manual for instructions on holding an attachment in the raised position when the cylinder lines are to be disconnected.

CENTER MOUNTED ATTACHMENTS

See figure 47. Center mounted attachments such as the rotary mower shown require the hitch assembly for center mounted attachments. They are hydraulically raised and lowered by the two lift cables connected to the rear hydraulic cylinder.

REAR MOUNTED ATTACHMENTS

See figure 48. The rotary tiller shown is an example of a rear mounted attachment. The optional three-point hitch is required to mount most rear mounted attachments. They can




Figure 47. Rotary mower - an example of a center mounted attachment.

be attached to the rear power take off (optional-factory installed only) if required. Page 36 of this manual gives instructions for mounting attachments to the three-point hitch and attaching the power take off. If you are using a front mounted attachment with an additional hydraulic cylinder, only the hose connection to one cylinder should be connected at a time.

See figure 53. The restraining chains can be moved from the eyebolts (B) to the frame holes (C) to hold the three-point hitch in the raised position while the hydraulic couplings are being disconnected or the hydraulic cylinder removed to be used in the front.

THREE POINT HITCH: (OPTIONAL - FACTORY OR FIELD INSTALLED) (Figure 49 and 50) The three-point hitch provides a versatile and convenient means of mounting and controlling rear mounted attachments such as




Figure 48. Rotary tiller - an example of a rear mounted attachment.




Figure 49. Three - point hitch.

a rotary tiller or moldboard plow. The three-point-hitch is activated by a hydraulic cylinder controlled by the hydraulic control lever. For more information on how to use the hydraulic control lever to operate the three-point-hitch, see page 5 of this manual.

DRAFT ARMS: The three point hitch on the Simplicity 4040 meets category O dimensions as set by the Society of Automotive Engineers and the American Society of Agricultural Engineers when the draft arms are fastened through the lower holes of the lower lift link (Figure 49, item A). However, because of the unique design of the 4040 tractor, a more effective line of pull to most attachments is achieved by fastening the draft arms through the upper holes of the lower lift link (Figure 50, item A). Unless the attachment owners manual specifies otherwise, the upper holes of the lower lift arms should be used as shown in figure 50.

FLOAT LOCKOUT PINS: When using attachments such as a Simplicity rotary tiller which has its own depth setting device, it is desirable to allow the draft arms to float (move freely up and down). To do this, remove the two spring clips and set the lockout pins with the larger end of the pins exposed (Figure 49, item B). Figure 50, item B shows the lockout pins set so the draft arms are held rigid to the rockshaft arm.

TURNBUCKLE LINK: The turnbuckle link is used to level the attachment fore and aft when at its working depth. Hitching an attachment is made easier by adjusting the link to align the pin holes. To adjust the length of the link, turn the center turnbuckle until the desired length is obtained. The turnbuckle link is adjustable 11-1/2 to 15 inches in length. In addition, two holes are provided in the mounting bracket for attaching the upper link to the tractor. Unless the owners manual for an attachment specifies otherwise, use the top hole (Figure 50, item C). Figure 49, item C shows the turnbuckle attached to the lower hole of the mounting bracket.




Figure 50. Three - point hitch.

CENTER LIFT CABLES: When a center mounted attachment such as the sickle bar or center mounted mower is used, the lift cables should be fastened to the rocker arm with the two pins and spring clips (Figure 49, item D). When no center attachment is mounted the pins and spring clips should be removed as shown at figure 50, item (D) and used to fasten the front of the cables to the underside of the tractor foot rests (Figure 51, item A).

RESTRAINING CHAINS: The restraining chains are used to prevent an attachment mounted to the three point hitch from swinging too far to the left or right. The length of the chains can be adjusted by removing the pin and spring clip from the U link and placing the U link through the desired chain link. The eyebolts which fasten the restraining chains to the drawbar should be mounted in the drawbar so the chains are fastened above the drawbar when it is desirable to




Figure 51. Center lift cable attached to footrest.




Figure 52. Mounting attachments to the three-point hitch.

restrain the attachment equally whether it is lowered or raised (Figure 49, item E). They should be attached in this manner when the rotary tiller is used. When using an attachment such as a plow where less restraint is required when it is in the lowered position and more restraint in the raised position, the eyebolts should be turned around so the chains are hooked below the drawbar (Figure 50, item E). If the drawbar has been removed to allow additional clearance such as when cultivating, the eyebolts for the restraining chains can be placed through the lower drawbar mounting holes in the frame. See the attachment manual for more information.

LEVELING CRANKS: (Figure 49, item F) The two leveling cranks can be used to level an attachment mounted to the three point hitch. They can also be used to change the high and low limits of the draft arms. Turn them clockwise if you wish the hitch to raise higher and counter-clockwise to allow the hitch to be lowered closer to the ground. The leveling cranks are also convenient for adjusting the height of the draft arms when hitching an attachment.

REMOVING THE THREE POINT HITCH: The three point hitch may be easily removed from the tractor by removing the spring clips and pins at the 7 positions marked C, E, and F in figure 50. Although the pins holding the draft arms to the tractor frame will not slide all the way out, the spacer and draft arms will slide off the end of the pin after the spring clip has been removed.

MOUNTING ATTACHMENTS TO THE THREE POINT HITCH: (Figure 52) Mounting attachments to the three point hitch is not difficult, but here are some helpful pointers.




Figure 53. Attaching a power take off shaft.

Mounting is easier if the attachment and tractor are on a level surface. Back the tractor straight toward the front of the attachment until the swivel sockets at the ends of the draft arms are in line with the attachment hitching pins. Use the hydraulic control lever to level the draft arms so the swivel sockets are the same height as the attachment hitch pins. Stop the tractor engine. Place the swivel sockets on the attachment lift pins (A). Turning the crank handles to align the holes will make hitching easier. Insert the safety pins through the holes in the implement hitch pin.

ATTACHING POWER TAKE OFF: (Figure 53) If the attachment is driven by the rear power take off drive, hook up the power take off drive shaft at this time before attaching the turnbuckle link. **CAUTION: BE SURE THE TRACTOR ENGINE IS STOPPED.** Start the drive shaft spline in the internally splined power take off. While holding the drive shaft in place with one hand, use the other to turn the outer locking ring (A) of the power take off drive clockwise and hold it there. Slide the power take off shaft into the drive and release the locking ring. Insure the locking pins have seated in the groove of the power take off drive by attempting to pull the drive shaft out. To remove the drive shaft, turn the locking ring clockwise and pull the drive shaft out.

Align the swivel at the end of the turnbuckle with the holes through the tower of the attachment and insert the pin and safety ring (Figure 48, item A). The turnbuckle may be adjusted to aid in aligning the holes. Level the draft arms and adjust the length of the turnbuckle link according to the attachment owners manual.

SPECIFICATIONS

ENGINE

Make	Onan
Model	CCKA
Cycle	4
Fuel	Gasoline
Cylinders	2 (opposed)
Cylinder Material	Cast Iron
Cylinder Bore	3 - 1/4 inches
Stroke	3 inches
Piston Displacement	49.8 Cubic Inches
Horsepower @ 3600 RPM	16.5
Compression Ratio	7.0 to 1
High Speed (No Load)	3850 RPM (Revolutions per Minute) Maximum
High Speed (Full Load)	3600 RPM
Idle Speed	1200 RPM
Valves	Positive rotating Stellite facing on valve heads
Valve Tappet Clearance	Intake .006" - .008" Exhaust .015" - .017"
Valve Seats	Replaceable, Stellite faced
Cooling System	Pressure air cooled, axial flow blower
Carburetor	Marvel-Schebler, downdraft, fixed main jet
Fuel Filter	In fuel line
Choke	Manually operated
Air Cleaner	Replaceable paper element
Fuel Pump	Diaphragm type
Governor	Cam gear driven, adjustable mechanical flyball, pressure lubricated
Breaker point gap	0.020 inch
Ignition Timing	20° before top dead center

Spark Plug	Champion H-8 or equivalent
Spark plug gap	0.025 inch
Lubrication System	Gear type oil pump, adjustable pressure relief valve, replaceable oil filter
Starting Motor	12 volt electric solenoid shift starter
POWER TRAIN	
Clutch	Foot pedal operated, double V-belt drive, clutched by varying center distance between pulleys
Universal Joints	Disc type, self aligning, no moving parts
Hydrostatic Transmission	Sundstrand — Variable delivery piston type pump with fixed stroke piston type motor. Replaceable oil filter.
Gear Transmission	3-Speed Sliding Spur gear, Cast iron transmission case, Rolling contact bearings
Differential	8 pinion, spur gear, non-adjustable limited slip. Located in transmission case.
Final Drive	Individual spur gears, rolling contact bearings, cast iron case.
STEERING	
Type	Recirculating ball screw, manual operation.
Steering wheel revolutions	3.2 stop to stop
Steering wheel diameter	14"
SEAT	
Standard Seat	Adjustable 4 inches front to rear - 5 position
Optional lever operated seat	Adjustable from operator position - 4 inches front to rear. Spring mounted, inclined ramp.
FRONT POWER TAKE OFF	
Clutch	12 Volt electric solenoid actuated
Speed	Equal to engine RPM
Drive	6 1/2 inch A section pulley
REAR POWER TAKE OFF (Optional)	
Clutch	12 Volt electric solenoid actuated
Speed (@ 3600 Engine RPM)	2000 RPM (55% of engine RPM)

Drive	1" Internal 15 tooth involute spline
Direction of Rotation	Clockwise (viewed from the rear)
POWER LIFT SYSTEM	
Type	Hydraulic
Hydraulic Pump	2-1/4 GPM (Gallons per Minute) Hydrostatic Transmission charge pump
Relief Valve Pressure	500 PSI (Pounds per Square Inch)
Control	Hand Operated
Hydraulic Cylinder	2.25 inch diameter - 4 inch stroke
3 POINT HITCH	
Type	Flexible Swinging draft hubs with ball couplers
SAE & ASAE Category	Meets Category O Dimensions
Control	Hand operated - same as power lift system
DRAWBAR	
Type	Single position - removable
Height	13 inches
Pin Size	3/4 inch
BRAKES	
	Individual double disk type, can be locked together for simultaneous operation, parking brake is cam locking type.
ELECTRICAL SYSTEM	
Battery	53 Ampere hour 12 volt SAE group size 9MJ3C sealed terminals
Alternator	20 Ampere flywheel alternator with silicon diode rectifier
Regulator	Transistorized temperature compensated voltage regulator
Protection	30 Ampere fuse for alternator 20 ampere circuit breaker for auxiliaries
Lights	Fender mounted sealed beams
WHEELS AND TIRES	
Size	Front Agricultural 4.00 x 12 (Standard) Turf 20 x 8 - 10 (optional)

	High Capacity 6.00 x 9 (optional)	
	Rear	
	Agricultural 8 x 16 (Standard)	
	Turf 29 x 12.50 - 15 (optional)	
	High Flotation 31 x 15.50 - 15 (optional)	
Tread Width	See the chart on page 21.	
Tire Pressure	See the chart on page 23.	
LIQUID TYPE AND CAPACITY		
Fuel Tank (Regular gasoline)	3.8 gallons	
Engine Crankcase (Above 30°F - SAE 30, Below 30°F - SAE 5W-30)	3.5 quarts	
Transmission and Hydraulic System (Type A, Type F, or Dexron)	6.0 quarts	
Axle Housings, each (90 Wt. Trans. Oil)	0.5 quarts	
DIMENSIONS		
Wheel Base	56 inches	
Length (overall)	83 inches	
Height (overall)	48 inches	
Width (overall)		
With Agricultural tires (narrow setting)	43-1/4 inches	
With Agricultural tires (wide setting)	48 inches	
With Turf tires	50 - 1/2 inches	
With High Flotation tires	56 - 1/2 inches	
Ground Clearance (without drawbar)	15 inches	
Turning Radius (With agricultural tires at wide tread setting)	OUTSIDE FRONT TIRE	INSIDE REAR TIRE
Without using brake	8'	3'
Using Steering Brakes	6'	1'
WEIGHT		
Shipping weight	1300 pounds (approximate)	
Operating weight		
With 180 lb. operator	Rear — 1000 pounds (approximate)	
	Front — 480 pounds (approximate)	
GROUND SPEED		
(Approximate - Engine at 3600 RPM)	FORWARD	REVERSE
Gear Range		
1	0 - 4.2 MPH	0 - 2.6 MPH
2	0 - 6.3 MPH	0 - 4.0 MPH
3	0 - 10.4 MPH	0 - 6.2 MPH

INDEX

Accessories	32	Ignition timing, setting	28
Adjustments	15	Inspect the tractor and engine	23
Air filter	25, 29	Instruments and controls	4
Ammeter	5	Leveling cranks	36
Attaching power take off	36	Light switch	5
Attachments	34	Lubricate grease fittings	25
Auxiliary control switch	5	Maintenance	23
Battery water level	23	Maintenance chart	24
Before operating the tractor	8	Mounting attachments to the three point hitch	36
Brake adjustment	18	Neutral safety starting switch	18
Brakes	7	Oil pressure warning light	5
Break in procedure	9	Operation	4
Breaker points, change	27	Operation chart	10, 11
Carbon and lead deposits, remove	30	Ordering replacement parts	23
Carburetor adjustment	15	Out of service protection (storage)	12
Center lift cables	35	Parking brake lock	7
Center mounted attachments	34	Protect yourself and others	2
Choke control knob	4	Rear clutch	5
Clutch pedal	6	Rear mounted attachments	34
Clutch pedal free travel	16	Rear wheel weights	32
Cold weather operation	12	Removing the 3-point hitch	36
Controlling tractor ground speed	9	Restraining chains	35
Crankcase breather valve, clean	28	Scheduled maintenance chart	24
Draft arms	35	Seat adjustment	7, 19
Drop housing oil level	27	Seat adjusting lever	7
Dusty operating conditions	12	Selecting transmission gear	9
Engine crankcase oil level	23	Spark plugs, change	26
Engine fins, clean	29	Specifications	37-40
Engine oil, change	25	Starting the engine	8
Engine oil filter, replace	26	Starting the tractor after storage	12
Engine speed	9	Starting tractor travel	9
Engine speed control lever	4	Stopping the engine	8
Engine valve tappet clearance	31	Stopping tractor travel	9
Float lockout pins	35	Three Point Hitch	34
Front bumper	33	Three speed transmission shift lever	6
Front clutch	5	Tire chains	32
Front mounted attachments	34	Tire pressure	23
Front wheel bearings, repack	29	Traction clutch belt tension	16, 26
Fuel filter, replace	27	Transmission oil (fluid), change	29
Fuel gauge and filler cap	5	Transmission oil (fluid) cooler	23
Governor adjustment	15	Transmission oil (fluid) level	23
Governor linkage, clean	28	Transmission oil temperature warning light	5
Hot weather operation	9	Trouble shooting guide	13, 14
Hourmeter	5	Turnbuckle link	35
Hydraulic cylinder	32	Warranty	1
Hydraulic lift control lever	5	Weighting with calcium chloride	22
Hydrostatic transmission control lever	6, 9	Wheel and tire options	20
Hydrostatic transmission neutral adjustment	17	Wheel tread adjustment	19, 21
Ignition switch	4		

NOTES

NOTES

NOTES



CAUTION

1. Keep all shields in place.
2. Before leaving operator's position:
 - Shift transmission to neutral.
 - Set parking brake.
 - Disengage attachment clutch.
 - Shut off engine.
 - Remove ignition key.
3. Wait for all movement to stop before servicing machine.
4. Keep people and pets a safe distance away from machine.

